

---

# Zlinx Wireless I/O



---

# Zlinx Wireless I/O

Documentation Number: ZlinxIO-0712m

*This product was designed and manufactured in Ottawa, Illinois USA*

*Using domestic and imported parts by*



## **International Headquarters**

B&B Electronics Mfg. Co. Inc.

707 Dayton Road

Ottawa, IL 61350 USA

**Phone:** (815) 433-5100 **General Fax:** (815) 433-5105

Website: [www.bb-elec.com](http://www.bb-elec.com)

## **European Headquarters**

B&B Electronics Ltd.

Westlink Commercial Park

Oranmore, Co. Galway, Ireland

**Phone:** (+353) 91-792444 **Fax:** (+353) 91-792445

Website: [www.bb-europe.com](http://www.bb-europe.com)

---

©2009 B&B Electronics Mfg Co Inc. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photography, recording, or any information storage and retrieval system without written consent. Information in this manual is subject to change without notice, and does not represent a commitment on the part of B&B Electronics Mfg Co Inc.

B&B Electronics Mfg Co Inc. shall not be liable for incidental or consequential damages resulting from the furnishing, performance, or use of this manual. All brand names used in this manual are the registered trademarks of their respective owners. The use of trademarks or other designations in this publication is for reference purposes only and does not constitute an endorsement by the trademark holder.

---

# CONTENTS

---

<b>1. OVERVIEW</b>	<b>1</b>
1.1 NOTICES	1
1.2 PREREQUISITES	1
1.3 SAFETY INFORMATION	1
1.4 UL & cUL INSTALLATION INFORMATION	1
1.5 ABOUT THIS MANUAL	3
1.6 ZLINX WIRELESS I/O PRODUCT SPECIFICATION SUMMARY	5
<b>2. PRODUCT INTRODUCTION</b>	<b>6</b>
2.1 ZLINX WIRELESS I/O PRODUCT FAMILY	6
2.2 ZLINX WIRELESS I/O MODES OF OPERATION	6
2.2.1 <i>Peer-to-Peer Mode</i>	6
2.2.2 <i>Modbus Mode</i>	7
2.2.3 <i>Repeater Mode</i>	8
2.2.3.1 Configuring Modbus Radio Modem as a repeater	8
2.3 PACKAGE CONTENTS	9
2.4 FEATURES	10
2.5 RADIO FREQUENCY BASICS	11
2.5.1 <i>What is dBm?</i>	11
2.5.2 <i>Lower Frequencies - Better Propagation</i>	11
2.5.3 <i>Range Performance</i>	11
2.5.4 <i>RF Noise</i>	12
2.5.5 <i>Fade Margin</i>	12
2.5.6 <i>Remember Your Math</i>	12
2.5.7 <i>RF Attenuation and Line of Sight</i>	12
2.5.7.1 Path Loss Rules of Thumb	13
2.5.7.2 Antennas	13
2.5.7.3 Cable Loss	14
<b>3. HARDWARE INFORMATION</b>	<b>15</b>
3.1 RECOMMENDED PRACTICE BEFORE INSTALLATION	15
3.2 ZLINX WIRELESS I/O MODULES	15
3.2.1 <i>Base Modules</i>	16
3.2.2 <i>Expansion Modules</i>	16
3.2.3 <i>Configuration Box</i>	17
3.3 I/O OPTIONS AND CHARACTERISTICS	17
3.3.1 <i>I/O Options</i>	17
3.3.2 <i>I/O Types and Characteristics</i>	18
3.3.2.1 Digital Inputs	18
3.3.2.2 Digital Outputs	18
3.3.2.3 Analog Inputs	18
3.3.2.4 Analog Outputs	18
3.3.3 <i>I/O Wiring</i>	20
3.3.3.1 DI Wiring	20
3.3.3.2 DO Wiring	20
3.3.3.3 AI Wiring	21
3.3.3.4 AO Wiring	22
3.3.3.5 RTD Wiring	25
3.3.4 <i>Modbus I/O Addressing</i>	25
3.3.4.1 Function Field and Modbus I/O Addressing	27
3.3.5 <i>Modbus Counters</i>	27
3.4 ACCESSORIES	28
3.4.1 <i>LED Indicators</i>	28
3.4.1.1 Power LED	28
3.4.1.2 RSSI LED	28
3.4.1.3 RF Data LED	28
3.4.1.4 Bus LED	28

3.4.2	<i>Antennas</i> .....	28
3.4.3	<i>Connectors</i> .....	29
3.4.3.1	Antenna Connector .....	29
3.4.3.2	Power Supply Connector .....	29
3.4.3.3	Serial Port Connector.....	29
3.4.3.4	Local Bus Connectors.....	29
3.4.3.5	I/O Connectors.....	30
3.4.4	<i>Mounting Hardware</i> .....	31
<b>4.</b>	<b>SETUP</b> .....	<b>32</b>
4.1	ZLINX WIRELESS I/O INSTALLATION .....	32
4.1.1	<i>Power Supply Requirements</i> .....	32
4.1.2	<i>RF Site Considerations</i> .....	32
4.1.3	<i>Zlinx Wireless I/O Mounting</i> .....	33
4.2	COMPUTER SYSTEM REQUIREMENTS .....	33
4.3	INSTALLING ZLINX WIRELESS I/O SOFTWARE .....	33
4.4	INSTALLING ZZ-PROG1-USB DRIVERS.....	33
4.5	CONNECTING ZLINX WIRELESS I/O TO A PC .....	34
4.6	STARTING ZLINX I/O CONFIGURATION .....	34
4.7	ZLINX I/O CONFIGURATION OPTIONS .....	37
4.7.1	<i>Information Tab</i> .....	37
4.7.2	<i>Configuration Tab</i> .....	37
4.7.3	<i>Input/Output Tab</i> .....	37
<b>5.</b>	<b>CONFIGURATION &amp; OPERATION</b> .....	<b>38</b>
5.1	CONFIGURING ZLINX WIRELESS I/O .....	38
5.1.1	<i>Wireless Settings</i> .....	38
5.1.2	<i>Modbus Mode Settings</i> .....	43
5.1.3	<i>Peer-to-Peer Mode Settings</i> .....	45
5.1.3.1	Peer-to-Peer Master .....	45
5.1.3.2	Peer-to-Peer Slave.....	46
5.1.4	<i>Input/Output Settings</i> .....	47
5.1.5	<i>Exception Reporting</i> .....	50
5.1.5.1	Sample Modbus Exception Packet.....	51
5.1.5.2	Digital Exception Format.....	51
5.1.5.3	Analog Exception Format .....	51
5.1.6	<i>Calibration</i> .....	52
5.1.7	<i>Failsafe</i> .....	54
5.1.8	<i>Communication Failure Alarm</i> .....	54
5.1.9	<i>Invert Output</i> .....	55
5.1.10	<i>Zlinx I/O Monitor</i> .....	55
5.1.11	<i>Saving the Configuration</i> .....	56
5.2	UPDATING ZLINX I/O FIRMWARE .....	56
5.3	DIAGNOSTICS AND TESTING .....	58
5.3.1	<i>Testing Modbus Mode Operation</i> .....	58
5.3.2	<i>Testing Peer-to-Peer Mode Operation</i> .....	58
<b>6.</b>	<b>EXPECTED LATENCY</b> .....	<b>59</b>
6.1	MODBUS MODE .....	59
6.2	PEER-TO-PEER MODE .....	60
<b>7.</b>	<b>RECEIVE SENSITIVITY</b> .....	<b>61</b>
<b>8.</b>	<b>SOFTWARE SUPPORT</b> .....	<b>62</b>
8.1	SUPPORT CD INFORMATION .....	62
8.2	MENU .....	62
8.3	ONLINE DOCUMENTATION.....	62
8.4	GETTING DOCUMENTS IN HARDCOPY .....	62
8.5	B&B ELECTRONICS INFORMATION .....	63

<b>9. TROUBLESHOOTING .....</b>	<b>64</b>
9.1 TESTING DIGITAL AND ANALOG I/O .....	65
9.1.1 <i>Testing DI</i> .....	65
9.1.2 <i>Testing DO with Sourcing Driver</i> .....	66
9.1.3 <i>Testing DO with Sinking Driver</i> .....	66
9.1.4 <i>Testing AI in "Voltage" Mode</i> .....	67
9.1.5 <i>Testing AO in "Voltage" Mode</i> .....	67
9.1.6 <i>Testing AI in "Current" Mode</i> .....	68
9.1.7 <i>Testing RTD module</i> .....	68
<b>APPENDIX A: DEFAULT CONFIGURATION SETTINGS .....</b>	<b>70</b>
<b>APPENDIX B: PRODUCT SPECIFICATIONS .....</b>	<b>71</b>
<b>APPENDIX C: DIMENSIONAL DIAGRAMS.....</b>	<b>74</b>
<b>APPENDIX D: MODBUS I/O ASSIGNMENTS.....</b>	<b>75</b>
<b>APPENDIX E: ZLINX WIRELESS I/O MODELS AND FEATURES.....</b>	<b>82</b>
<b>APPENDIX F: RTD MODULE.....</b>	<b>85</b>
<b>APPENDIX G: ZZ-4AO-2 MODULE.....</b>	<b>87</b>
<b>APPENDIX I: CONVERT VOLTAGE TO DAC .....</b>	<b>90</b>
<b>PRODUCT UPDATES .....</b>	<b>91</b>
<b>GLOSSARY .....</b>	<b>93</b>
<b>INDEX .....</b>	<b>95</b>



# 1. Overview

## 1.1 Notices

This equipment has been tested and found to comply with the limits for Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at personal expense.

Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operations.

This device must be operated as supplied by B&B Electronics. Any changes or modifications made to the device without the written consent of B&B Electronics may void the user's authority to operate the device.

## 1.2 Prerequisites

This manual assumes that you have basic electronics knowledge and basic understanding of wireless communications.

## 1.3 Safety Information

Exposure to RF energy is an important safety consideration. The FCC has adopted a safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated equipment as a result of its actions in Docket 93-62 and OET Bulletin 65 Edition 97-01.

### DO NOT:

- Operate unless all RF connectors are secure and any open connectors are properly terminated.
- Operate the equipment near electrical blasting caps or in an explosive atmosphere.

All equipment must be properly grounded for safe operations. All equipment should be serviced only by a qualified technician.

## 1.4 UL & cUL Installation Information

### Electrical Ratings

#### INPUT:

##### Base Modules:

ZZxxD-NA,NB-xx-xx, 10.0 - 40.0 VDC or 24 VAC, 2.7A maximum, Class 2.  
ZZxxD-NC,ND-xx-xx, 10.0 – 40.0 VDC or 24 VAC, 2.7A maximum, Class 2.

##### Expansion Modules (Class 2 power derived from base modules):

ZZ-2AI2AO, ZZ-4AI, ZZ-4AO, ZZ-4DI4DO-DCT1, ZZ-4RTD1, ZZ-8DI-DC,  
ZZ-8DO-R, ZZ-8DO-T1, ZZ-PROG1-USB:

10.0 - 40.0 VDC @ 210mA and 5.0 VDC 85 mA

ZZ-4AO-2: 10 – 40 Vdc or 24 Vac, 5 Vdc @ 50 mA, 1.1W

ZZ-4DI4DO-DCT, ZZ-8DO-T:

10.0 - 40.0 VDC @ 340 mA Maximum, and 5.0 VDC@50 mA Maximum

#### OUTPUT:

ZZ-8DO-R: relay output - 250 VAC, 2AGeneral Purpose/point, 8A General Purpose total

All other models – Low Voltage, Limited Energy communications protocol

**Special Precautions for UL and cUL Class I DIV 2 (C1D2)**

**The following modules are class 1 Div 2 listed:**

- ZZ24D-Nx-SR (2.4GHz, Short range base I/O Modules)
- ZZ9D-Nx-LR (900 MHz, Long range base I/O Modules)
- ZZ-2AI2AO
- ZZ-4AI
- ZZ-4AO
- ZZ-4AO-2
- ZZ-4DI4DO-DCT
- ZZ-4DI4DO-DCT1
- ZZ-4RTD1
- ZZ-8DI-DC
- ZZ-8DO-R
- ZZ-8DO-T
- ZZ-8DO-T1
- ZZ-PROG1-USB

**Class 1, Div 2 exceptions:**

**Note 1:** ZZ-8DO-R is not UL508 listed.

**Note 2:** ZZxxD-Nx-MR, ZZxxD-Nx-xR-AU and ZZ8D-Nx-xR models are not Class 1, Div 2 listed but are UL508 listed.

**WARNING – EXPLOSION HAZARD –** SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2

**WARNING – EXPLOSION HAZARD –** WHEN IN HAZARDOUS LOCATIONS, TURN OFF POWER BEFORE REPLACING ANTENNA

**WARNING – EXPLOSION HAZARD –** DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NONHAZARDOUS

THIS EQUIPMENT IS SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C, AND D OR UNCLASSIFIED LOCATIONS

Maximum Ambient Air Temperature 85°C (185°F) for all modules except ZZ-8DO-R.

For ZZ-8DO-R, maximum Ambient Air Temperature 55°C (131°F)

**WIRING TERMINALS:**

Copper wire only

One conductor per terminal

Wire range: 28 to 16 AWG

Tightening Torque: 1.7 lb-in.

Temperature rating of field wiring – 105 °C minimum (sized for 60°C ampacity).

**WARNING -** Two DIN rail end brackets, one on each end of of the assembled system, must be installed on the DIN rail to mechanically secure the individual products. Two end brackets are supplied with each Expansion module.

**The information below is specific to ZZ-8DO-R ONLY:**

Maximum Ambient Air Temperature 55°C (131°F)

Temperature Rating of Field Wiring – 105° C (221° F) minimum sized for 55° C (131°F) ampacity.

**WARNING –** Exposure to some chemicals may degrade the sealing properties of materials used in the Sealed Relays.



**RECOMMENDATION** – It is recommended to inspect the Sealed Relays periodically and to check for any degradation of the materials and to replace the product, not the Sealed Relays, if any degradation is found.

Relay Types JS-5N-K, JS-5-K, JS-6N-K or JS-6-K manufactured by **Takamisawa** Electric Co Ltd., rated 10A, 250VAC, 10A, 30VDC,utilizes the following materials to maintain sealed device properties:

	Manufacturer	Type
Relay Case	Mitsubishi Engineering Plastics Corp.	5010GN6-30(r2)
	Mitsubishi Engineering Plastics Corp.	5010GN6-30M8(cc)(r2)
	Mitsubishi Engineering Plastics Corp.	5010GN6-30 M8AM
Relay Base	Mitsubishi Engineering Plastics Corp.	5010GN6-30M8(cc)(r2)
	Mitsubishi Engineering Plastics Corp.	5010GN6-30 M8AM
Sealant	Eccobond	A-316SC

Relay Type APF-30305, manufactured by **Panasonic** Electric Works, rated 277VAC, 8A, 24VDC, 6A general use utilizes the following materials to maintain sealed device properties:

	Manufacturer	Type
Relay Case	Wintech Polymer Ltd.	CN7030MFBD
Relay Base	Wintech Polymer Ltd.	CN7015MFD
Sealant	Resinous Kasei Co. Ltd.	A-2500BK

## 1.5 About this manual

This manual has been created to assist you in installing, configuring, and using your Zlinx Wireless I/O modules. Please read it carefully and follow the instructions to achieve best results.

The manual is divided into 11 major sections as follows:

### Table of Contents

The table of contents is hypertext linked in the electronic documentation. This allows rapid navigation to each chapter.

### Overview

Overview section gives a general information on product standards compliance, prerequisites and safety information.

### Product Introduction

This section covers package contents, and main features of the Zlinx Wireless I/O products. This section also contains information on radio frequency basics.

### Hardware Information

In this section Zlinx Wireless I/O modules are described in details. The section covers information on I/O options and characteristics and wiring instructions.

### Getting Started

This section guides you through the installation process. Two main modes of operation: Peer-to-Peer mode and Modbus mode are introduced in this section.

### Configuration and Operation

Information on configuring Zlinx Wireless I/O is provided in the section. Information on settings for Peer-to-Peer and Modbus mode can be found in this section.

## **Software Support**

This section provides relevant information on obtaining product support.

## **Troubleshooting**

Possible problems that may be encountered and the ways to solve them are described in this section.

## **Appendixes**

Appendixes include all essential reference information for Zlinx Wireless I/O modules. Information found here includes a comprehensive references and useful tables of product properties.

## **Glossary**

Glossary covers main terms which are relevant to the understanding of the Zlinx Wireless I/O concept.

## **Index**

Index includes major terms and page numbers where referenced in the manual.

## 1.6 Zlinx Wireless I/O Product Specification Summary

Need to get a digital signal across a highway or river? Or just to the other end of your big warehouse? Zlinx Wireless I/O can do the job faster, easier, and less expensively than stringing cable. Easy plug-and-play set-up saves installation and maintenance time.

Despite their low price, these are not wimpy consumer or office products. Zlinx Wireless I/O is built to handle the heat, cold, and environments of industrial operations.

- Choice of number and type of digital and analog I/O.
- Ranges to 25 miles.
- Heavy Duty DIN mount, industrial grade case and components.
- Frequency ranges: ISM band, 902 to 928 MHz; 2.400 to 2.4385 GHz; 868 MHz.
- Modulation: FSK – Frequency Shift Keying.
- DSSS and FHSS Technology.
- Signal strength indicator aids troubleshooting.
- 3dBi for 868, 3 dBi for 900 MHz; 2.1 dBi for 2.4 MHz RPSMA male dipole.
- Wide temperature range -40C° to 80 C°.
- Versatile power: 10 to 40 VDC or 24 VAC.
- Software for Windows 7 and XP (Home or Professional with SP1 and SP2); Windows 2000 SP4; Vista 32 bit.
- Rugged circuitry, wide temperature – for indoor and outside applications.
- Handles most industrial control power configurations and power supplies.
- Immediate integration into UL/cUL or CSA approved panels.
- Exception Reporting option.
- Calibration option.
- Failsafe option.
- Communication Failure Alarm option.
- Invert Output option
- Zlinx I/O Monitor option.
- AES Encryption – 128 Bit on SR, LR-AU, and LR-868 models; 256 Bit on LR models
- Software Selectable Transmitter Power on SR, LR, LR-AU, and LR-868 models
- Software Selectable Over-the-air Data Rate on LR and LR-AU models.

## 2. Product Introduction

**Thank you for purchasing a Zlinx Wireless I/O product!** This product has been manufactured to the highest standards of quality and performance to ensure your complete satisfaction.

### 2.1 Zlinx Wireless I/O Product Family

**Zlinx Wireless I/O modules** provide easy-to-use, cost-effective Peer-to-Peer or Modbus wire-replacement solutions.



Figure 1 A Zlinx ZZ24D-NA-SR Base Module

The Zlinx Wireless I/O family of products features a selection of operational modes, communications ranges and I/O combinations. The system is scalable making it easy to start with a few I/O points and build a system with the required I/O mix.

### 2.2 Zlinx Wireless I/O Modes of Operation

Zlinx Wireless I/O systems can operate in Peer-to-Peer or Modbus modes. Some Base Modules can be configured as repeaters to extend the radio coverage distance.

#### 2.2.1 Peer-to-Peer Mode

In Peer-to-Peer mode two Zlinx Wireless I/O systems provide wire replacement functionality. In this mode one Base is configured as the Peer-to-Peer Master and the other as the Peer-to-Peer Slave. It does not matter which end of the link is the Master and which is the Slave. Both Base Modules must be the same model. Analog and Digital Input signals connected to AI's and DI's on one module appear on the corresponding AO's and DO's on the other module and vice versa. Any Expansion Modules included in a Peer-to-Peer system must be chosen to be complimentary. For example, if Expansion Module 1 on one end of the link on System-1 is a ZZ-4AI (4 Analog Inputs), Expansion Module 1 on the other end of the link on System-2 must be a ZZ-4AO (4 Analog Outputs). **Note: Changing the the OTA data rate to 9600 on the LR model will slow the data throughput. The approximate polling rate is one second.**

## Rules for Module Compatibility

The following rules of modules compatibility to run in Peer-to-Peer mode should be observed:

- ❑ Same number of Expansion Modules.
- ❑ Identical Radio units (in Base Modules).
- ❑ Complimentary Expansion Modules.
- ❑ Channel Number, Network ID, and Peer-to-Peer address must be the same for both Peer-to-Peer Master and Peer-to-Peer Slave to communicate with a Peer-to-Peer Slave.




Figure 2 Peer-to-Peer Mode

## 2.2.2 Modbus Mode

In Modbus mode standard RTU Modbus messages can be sent and received between a Modbus radio modem with attached Modbus device (being Master) and a Zlinx Wireless I/O system (being Slave). Data written to output addresses in the Zlinx Wireless I/O Modbus map result in signals appearing on its outputs. Signals connected to Zlinx Wireless I/O inputs are converted and stored in Modbus input memory locations and then sent across the link as Modbus messages to the Modbus radio modem.




Figure 3 Modbus Mode

## 2.2.3 Repeater Mode

When a Zlinx Wireless I/O Base Module is configured as a radio repeater it relays data from a Modbus modem or another Zlinx Wireless I/O Base Module and extends the range of communication.

If a repeater is needed in a Peer-to-Peer System a repeater unit can be placed between the Master and the Slave.

The repeater function is supported on the MR and ZZ9D-Nx-LR-xx models only.

The repeater function gives no true indication that the data is being "repeated", although you will see the RSSI LED on the device used as a repeater indicate GREEN, YELLOW or RED.

**NOTE:** *Placing a repeater in a system will slow the system down:*

*10ms for ZZ9D-Nx-LR-xx  
200ms for MR in Peer-to-Peer  
4ms for ZZ9D-Nx-LR-xx  
20ms for MR in Modbus*

If the repeater is desired in a Peer-to-Peer platform, it's best to use a Zlinx Wireless I/O Base Module as the repeater.

Without using a repeater confirm the Peer-to-Peer Master and Slave systems are communicating. Refer to section 5.3.2 "Testing Peer-to-Peer Mode".

Once it's established that the Master and Slave are communicating, the repeater can be introduced into the system.

The Zlinx Wireless I/O module used as a repeater **MUST** be placed in Modbus mode. This is done to keep the repeater device from accidentally responding to Peer-to-Peer packets sent by the Master device.

The repeater device must have the same Wireless parameters: "Channel", and "Network Identifier" as the Peer-to-Peer Master and Slave device.

The "Repeater" feature must be selected and updated to the Zlinx Wireless I/O module being used as the repeater.

To select the "Repeater" feature:

1. Go to the Zlinx I/O Configuration.
2. On the Configuration Tab enable "Repeater Mode".
3. Make sure to select Modbus mode.

The system is now configured as a repeater system and the data passed from the Master to the Slave will be passed through the repeater.

You can confirm repeater function by separating the Master and Slave until they stop communicating then place the repeater in the middle of the two.

### 2.2.3.1 Configuring Modbus Radio Modem as a repeater

If configuring a Modbus Radio Modem for repeater mode the following parameters need to be configured in addition to the Channel and Network ID.

- Set DT = 0xFFFF
- Set AM = to a unique value
- Set RP = 0x7F
- Set PK = 0xC9
- Set RB = 0xC9

- ❑ Set RO = 0x051d
- ❑ Set MD = 0x04
- ❑ If OTA Data Rate = 9600, ATRR and ATBR =0.




Figure 4 Using a Base Module as a Repeater

## 2.3 Package Contents

**Base Modules** are shipped with the following items included:

- ❑ Zlinx Wireless I/O module.
- ❑ Antenna.
- ❑ A printed version of the Modbus Mode Zlinx I/O Quick Start Guide.
- ❑ A printed version of the Peer-to-Peer Mode Zlinx I/O Quick Start Guide.

**Expansion Modules** are shipped with the following items included:

- ❑ Zlinx Wireless I/O module.
- ❑ A printed version of the Modbus Mode Zlinx I/O Quick Start Guide.
- ❑ A printed version of the Peer-to-Peer Mode Zlinx I/O Quick Start Guide.

### Configuration Modules

**ZZ-PROG1** is shipped with the following items included:

- ❑ ZZ-PROG1 Configuration Box.
- ❑ 6 foot DB9 male to DB9 female straight-through serial cable.
- ❑ A printed version of the Modbus Mode Zlinx I/O Quick Start Guide.
- ❑ A printed version of the Peer-to-Peer Mode Zlinx I/O Quick Start Guide.

**Configuration kits:**

**ZZ-PROGKIT** is shipped with the following items included:

- ❑ ZZ-PROG1 Configuration Box.
- ❑ 6 foot DB9 male to DB9 female straight-through serial cable.
- ❑ A printed version of the Modbus Mode Zlinx I/O Quick Start Guide.
- ❑ A printed version of the Peer-to-Peer Mode Zlinx I/O Quick Start Guide.
- ❑ A CD-ROM disc with:
  - Zlinx I/O Manager Configuration Software.
  - Zlinx I/O Firmware Updater.
  - USB Driver for ZZ-PROG1-USB
  - This manual in PDF format.
  - The Modbus Mode Zlinx I/O Quick Start Guide in PDF.
  - The Peer-to-Peer Mode Zlinx I/O Quick Start Guide in PDF.

**ZZ-PROG1-USB** is shipped with the following items included:

- ❑ ZZ-PROG1-USB Configuration Box with a USB interface instead of a serial interface.
- ❑ A printed version of the Modbus Mode Zlinx I/O Quick Start Guide.
- ❑ A printed version of the Peer-to-Peer Mode Zlinx I/O Quick Start Guide.
- ❑ 1 Meter Black USB cable.
- ❑ A CD-ROM disc with:
  - Zlinx I/O Manager Configuration Software.
  - Zlinx I/O Firmware Updater.
  - USB Driver for ZZ-PROG1-USB
  - This manual in PDF format.
  - The Modbus Mode Zlinx I/O Quick Start Guide in PDF format.
  - The Peer-to-Peer Mode Zlinx I/O Quick Start Guide in PDF format.

## 2.4 Features

- ❑ Choice of number and type of digital and analog I/O.
- ❑ Sourcing or sinking Digital Outputs available.
- ❑ Flexible and scalable by adding Expansion Modules.
- ❑ Wireless Modbus and Peer-to-Peer communications modes.
- ❑ Small, economical and configurable.
- ❑ Wide operating temperature range.
- ❑ AC or DC power sources.
- ❑ Four models with different radio options or different range capabilities.
- ❑ Power, RSSI, RF Data and Bus LED's.



- ❑ Removable screw terminal connectors for power supply and I/O points.
- ❑ Zlinx Manager Configuration Software.
- ❑ DIN rail mountable.

## 2.5 Radio Frequency Basics

### 2.5.1 What is dBm?

Radio Frequency (RF) power is measured in milli-Watts (mW) or, more usually in a logarithmic scale of decibels (dB), or decibels referenced to 1 mW of power (dBm). Since RF power attenuates as a logarithmic function, the dBm scale is most useful. Here are some examples of how these scales relate:

1mW = 0dBm	A 2-fold increase in power yields 3dBm of signal. A 10-fold increase in power yields 10dBm of signal. A 100-fold increase in power yields 20dBm of signal.
2mW = 3dBm	
4mW = 6dBm	
10mW = 10dBm	
100mW = 20dBm	
1W = 30dBm	

Figure 5 The dBm scale

### 2.5.2 Lower Frequencies - Better Propagation

Industrial applications typically operate in “license free” frequency bands, also referred to as ISM (Industrial, Scientific, and Medical). The frequencies and power of these bands varies from country to country. The most common frequencies encountered are:

- ❑ 2.4 GHz – nearly worldwide.
- ❑ 915 MHz band – North America, South America, and some other countries.
- ❑ 868 MHz band – Europe.

As frequency rises, available bandwidth typically rises, but distance and ability to overcome obstacles is reduced. For any given distance, a 2.4 GHz installation will have roughly 8.5 dB of additional path loss when compared to 900 MHz. However, lower frequencies require larger antennas to achieve the same gain.

### 2.5.3 Range Performance

The more sensitive the radio is, the lower the power signal it can successfully receive, stretching right down to the noise floor. There is so much variety in specifications for radio sensitivity, that it is difficult to make a meaningful comparison between products. The most meaningful specification is expressed at a particular bit error rate and will be given for an ideal environment shielded from external noise. Unless you are in a high RF noise environment, typically resulting from numerous similar-frequency radio transmitters located nearby, the odds are good that the noise floor will be well below the receive sensitivity, so the manufacturer’s rated receive sensitivity will be a key factor in your wireless system and range estimates.

You can often improve your receive sensitivity, and therefore your range, by reducing data rates over the air. Receive sensitivity is a function of the transmission baud rate so, as baud rate goes down, the receive sensitivity goes up. Many radios give the user the ability to reduce the baud rate to maximize range.

The receive sensitivity of a radio also improves at lower frequencies, providing another significant range advantage of 900 MHz (vs. 2.4 GHz) - as much as six to twelve dB!

## 2.5.4 RF Noise

RF background noise comes from many sources, ranging from solar activity to high frequency digital products to all forms of other radio communications. That background noise establishes a noise floor which is the point where the desired signals are lost in the background ruckus. The noise floor will vary by frequency.

Typically the noise floor will be lower than the receive sensitivity of your radio, so it will not be a factor in your system design. If, however, you're in an environment where high degrees of RF noise may exist in your frequency band, then use the noise floor figures instead of radio receive sensitivity in your calculations. If you suspect this is the case, a simple site survey to determine the noise floor value can be a high payoff investment.

When in doubt, look around. Antennas are everywhere nowadays - on the sides of buildings, water towers, billboards, chimneys, even disguised as trees. Many sources of interference may not be obvious.

## 2.5.5 Fade Margin

Fade margin is a term critical to wireless success. Fade margin describes how many dB a received signal may be reduced by without causing system performance to fall below an acceptable value. Walking away from a newly commissioned wireless installation without understanding how much fade margin exists is the number one cause of wireless woes.

Establishing a fade margin of no less than 10dB in good weather conditions will provide a high degree of assurance that the system will continue to operate effectively in a variety of weather, solar, and RF interference conditions.

There are a number of creative ways to estimate fade margin of a system without investing in specialty gear. Pick one or more of the following and use it to ensure you've got a robust installation:

- ❑ Some radios have programmable output power. Reduce the power until performance degrades, then dial the power back up a minimum of 10dB. Remember again, doubling output power yields 3 dB, and an increase of 10dB requires a ten-fold increase in transmit power.
- ❑ Invest in a small 10dB attenuator - pick the correct one for your radio frequency! If you lose communications when you install the attenuator installed in-line with one of your antennas, you don't have enough fade margin.
- ❑ Antenna cable has greater attenuation at higher frequencies. Specifications vary by type and manufacturer so check them yourself but, at 900 MHz, a coil of RG58 in the range of 50 to 100 feet (15 to 30 m) will be 10dB. At 2.4GHz, a cable length of 20-40 feet (6 to 12 m) will yield 10dB. If your system still operates reliably with the test length of cable installed, you've got at least 10dB of fade margin.

## 2.5.6 Remember Your Math

Contrary to popular opinion, no black art is required to make a reasonable prediction of the range of a given radio signal. Several simple concepts must be understood first, and then we can apply some simple rules of thumb.

The equation for successful radio reception is:

***TX power + TX antenna gain – Path loss – Cabling loss + RX antenna gain – 10dB fade margin > RX Radio sensitivity or (less commonly) RF noise floor***

Note that most of the equation's parameters are easily gleaned from the manufacturer's data. That leaves only path loss and, in cases of heavy RF interference, RF noise floor as the two parameters that you must establish for your particular installation.

In a perfect world, you will measure your path loss and your RF noise conditions. For the majority of us that don't, there are rules of thumb to follow to help ensure a reliable radio connection.

## 2.5.7 RF Attenuation and Line of Sight

In a clear path through the air, radio signals attenuate with the square of distance. Doubling range requires a four-fold increase in power, therefore:

- ❑ Halving the distance decreases path loss by 6dB.
- ❑ Doubling the distance increases path loss by 6dB.

When indoors, paths tend to be more complex, so use a more aggressive rule of thumb, as follows:

- ❑ Halving the distance decreases path loss by 9dB.
- ❑ Doubling the distance increases path loss by 9dB.

Radio manufacturers advertise “line of sight” range figures. Line of sight means that, from antenna A, you can see antenna B. Being able to see the building that antenna B is in does not count as line of sight. For every obstacle in the path, de-rate the “line of sight” figure specified for each obstacle in the path. The type of obstacle, the location of the obstacle, and the number of obstacles will all play a role in path loss.

Visualize the connection between antennas, picturing lines radiating in an elliptical path between the antennas in the shape of a football. Directly in the center of the two antennas the RF path is wide with many pathways. A single obstacle here will have minimal impact on path loss. As you approach each antenna, the meaningful RF field is concentrated on the antenna itself. Obstructions located close to the antennas cause dramatic path loss.

Be sure you know the distance between antennas. This is often underestimated. If it's a short-range application, pace it off. If it's a long-range application, establish the actual distance with a GPS or Google Maps.

The most effective way to reduce path loss is to elevate the antennas. At approximately 6 feet high (2 m), line of sight due to the Earth's curvature is about 3 miles (5 km), so anything taller than a well-manicured lawn becomes an obstacle.

Weather conditions also play a large role. Increased moisture in the air increases path loss. The higher the frequency, the higher the path loss.

Beware of leafy greens. While a few saplings mid-path are tolerable, it's very difficult for RF to penetrate significant woodlands. If you're crossing a wooded area you must elevate your antennas over the treetops.

Industrial installations often include many reflective obstacles leading to numerous paths between the antennas. The received signal is the vector sum of each of these paths. Depending on the phase of each signal, they can be added or subtracted. In multiple path environments, simply moving the antenna slightly can significantly change the signal strength.

Some obstacles are mobile. More than one wireless application has been stymied by temporary obstacles such as a stack of containers, a parked truck or material handling equipment. Remember, metal is not your friend. An antenna will not transmit out from inside a metal box or through a storage tank.

### 2.5.7.1 Path Loss Rules of Thumb

To ensure basic fade margin in a perfect line of sight application, never exceed 50% of the manufacturer's rated line of sight distance. This in itself yields a theoretical 6dB fade margin – still short of the required 10dB.

De-rate more aggressively if you have obstacles between the two antennas, but not near the antennas.

De-rate to 10% of the manufacturer's line of sight ratings if you have multiple obstacles, obstacles located near the antennas, or the antennas are located indoors.

### 2.5.7.2 Antennas

Antennas increase the effective power by focusing the radiated energy in the desired direction. Using the correct antenna not only focuses power into the desired area but it also reduces the amount of power broadcast into areas where it is *not* needed.

Wireless applications have exploded in popularity with everyone seeking out the highest convenient point to mount their antenna. It's not uncommon to arrive at a job site to find other antennas sprouting from your installation point. Assuming these systems are spread spectrum and potentially in other ISM or licensed frequency bands, you still want to maximize the distance from the antennas as much as possible. Most antennas broadcast in a horizontal pattern, so vertical separation is more meaningful than horizontal separation. Try to separate antennas with like-polarization by a minimum of two wavelengths, which is about 26 inches (0.66 m) at 900 MHz, or 10 inches (0.25 m) at 2.4 GHz.

### 2.5.7.3 Cable Loss

Those high frequencies you are piping to your antennas don't propagate particularly well through cable and connectors. Use high quality RF cable between the antenna connector and your antenna and ensure that all connectors are high quality and carefully installed. Factor in a 0.2 dB loss per coaxial connector in addition to the cable attenuation itself. Typical attenuation figures per 10 feet (3 meters) for two popular cable types are listed below.

Frequency	Cable Types	
	RG-58U*	LMR-400*
900 MHz	1.6 dB	0.4 dB
2.4 GHz	2.8 dB	0.7 dB

\*Loss per 10 feet (3 meters) of cable length

Figure 6 Attenuation figures

While long cable runs to an antenna create signal loss, the benefit of elevating the antenna another 25 feet (7.6 m) can more than compensate for those lost dB.

## 3. Hardware Information

### 3.1 Recommended Practice Before Installation

Before installing a new system, it is preferable to bench test the complete system as configuration problems are easier to recognize when the system units are close together.

Following installation, poor communications can be caused by:

- Incorrectly installed antennas.
- Radio interference.
- Obstructions in the radio path.
- Radio path too long.

If the radio path is a problem, higher performance antennas may help.

Please set up a bench test and familiarize yourself with a pair or set of these modules before taking them out into the field for installation. For testing analog and digital I/O see section 9.1 "Testing Digital and Analog I/O".

### 3.2 Zlinx Wireless I/O Modules

**Zlinx Wireless I/O** encompasses a growing family of products including Base Modules, Expansion Modules, Configuration Boxes, configuration software and accessories. All modules are built into similar enclosures featuring male local bus plugs and female local bus receptacles on the sides, which allow modules to connect together (except Base Modules which do not have left-side connector and Configuration Boxes which do not have right-side connectors). Modules are DIN rail mountable and feature removable screw terminal blocks.

Zlinx Wireless I/O modules are configured using a Configuration Box, connected to a PC and running Zlinx Manager Software. Zlinx Wireless I/O systems can operate in Modbus or Peer-to-Peer modes. In Modbus mode a Zlinx Wireless I/O system exchanges Modbus messages with a Modbus radio modem. In Peer-to-Peer mode two Zlinx Wireless I/O systems provide wire-replacement functionality. Some Base Modules can also be used as repeaters, to extend the communication distance of a system.

**NOTE:** Refer to section 2.2 "Zlinx Wireless I/O Modes of Operation" for more information.



Figure 7 Front View of Zlinx Wireless I/O Base, Configuration Box, and Expansion Modules,

### 3.2.1 Base Modules

Each Zlinx Wireless I/O system is built around a **Base Module**. Base Modules provide digital and/or analog I/O, and radio communications with other Zlinx nodes.




Figure 8 A Typical Base Module (2AI-2AO-2DI-2DO)

Radio options include three frequency bands 2.4 GHz, 900 MHz, and 868 MHz (868 band is applied in Europe and due to the single-channel band, to prevent excessive interference between radios regulations require radios to not exceed a 10% transmission duty cycle. This means that the radio can only be transmitting 10% of the time), and three power output/range categories: Short Range, Medium Range, and Long Range.

Frequency Band	Range Category	Indoor	Outdoor (Line of Sight)
2.4 GHz	Short Range (SR)	300 ft	1 mile
2.4 GHz	Medium Range (MR)	600 ft	3 miles
900 MHz	Medium Range (MR)	1500 ft	7 miles
900 MHz	Long Range (LR)	1800 ft	25 miles
868 MHz	Long Range (LR)	1800 ft	25 miles

Figure 9 Radio Type Options and Ranges (with included antennas)

Several different combinations of Digital Inputs (DI), Digital Outputs (DO), Analog Inputs (AI) and Analog Outputs (AO) are available. For example, the ZZ24D-NA-SR features a combination of two DI's, two DO's, two AI's, and two AO's in a package with a short range (SR) 2.4 GHz radio option. Similar models are available with Medium Range (MR) and Long Range (LR) radio options.

### 3.2.2 Expansion Modules

Up to six **Expansion Modules** can be plugged into the Base Module to add more I/O capabilities in any combination needed. For example, the ZZ-8DO-T Expansion Module provides eight additional Digital Outputs; the ZZ-2AI2AO provides two Analog Inputs and two Analog Outputs.

**NOTE:** Refer to "Appendix E: Zlinx Wireless I/O Models and Features" for a list of Zlinx Wireless I/O models and features.

Expansion Modules connect to Base Modules by plugging the modules together, engaging the local bus connectors located on the sides of the boxes. Male plugs on Expansion Modules plug into female connectors on the side of the Base Module or

other Expansion Modules, resulting in a horizontal “stack” with the Base Module on the left and Expansion Modules extending to the right.




Figure 10 Base and Expansion Modules Connected Together

### 3.2.3 Configuration Box

The ZZ-PROG1 or ZZ-PROG1-USB **Configuration Boxes** provide a convenient way to interface Base and Expansion Modules with a PC and the software used to configure them. The Configuration Box plugs into a Base or Expansion Module on the right hand side. The Configuration Box connects to a PC serial port (COM1 to 16) using a standard straight-through 9-pin serial cable unless you are using the ZZ-PROG1-USB model which uses a USB cable.




Figure 11 A PC, Configuration Box and Base Module

## 3.3 I/O Options and Characteristics

### 3.3.1 I/O Options

The Zlinx Wireless I/O family of products features a variety of input and output options. Base and Expansion Module options include:

- 2 Analog Inputs, 2 Analog Outputs, 2 Digital Inputs and 2 Digital Outputs (sourcing or sinking driver).
- 4 Digital Inputs and 4 Digital Outputs (sourcing or sinking driver).
- 8 Digital Inputs.
- 8 Digital Outputs (sourcing or sinking driver) and relay.

- 4 Analog Inputs.
- RTD Temperature input module.
- 4 Analog Outputs.
- 2 Analog Inputs and 2 Analog Outputs.

Modules continue to be developed with additional features and options.

**NOTE:** Refer to "Appendix E: Zlinx Wireless I/O Models and Features" for a list of available models and options.

## 3.3.2 I/O Types and Characteristics

### 3.3.2.1 Digital Inputs

DI's can detect the presence of contact closures, transistor switches or on/off DC voltage signals (low or high logic levels). Voltages below 0.8 VDC are interpreted as a low state. Voltages between 4.0 VDC and 48 VDC are interpreted as a high state. The state of voltages between 0.8V and 4.0V are undefined.

In Peer-to-Peer mode the outputs are active because the Digital Inputs on the corresponding complimentary system are pulled high. Connecting the Digital Inputs to a 10K pull down resistor would bring the DO's low or inactive as a default.

**NOTE:** Inputs have an internal "weak" pull-up resistor so unconnected inputs will read as being in the high state.

### 3.3.2.2 Digital Outputs

Digital Outputs send on/off signals (low or high logic levels) to drive external devices such as indicators, relay coils or the inputs of other equipment such as PLC's, SCADA, etc. Modules with Digital Outputs are available with sourcing or sinking drivers and relay.

Sourcing (PNP transistor) drivers provide up to 40mA per output (or 320mA total for an 8 DO module) at output voltages up to 40 VDC to connected loads.

Sinking (NPN transistor) drivers can sink up to 40 mA per output (or 320mA total for an 8 DO module) at voltages up to 48 VDC.

### 3.3.2.3 Analog Inputs

Analog Inputs accept voltage, current signals, or RTD temperature signals. When configured as voltage inputs the full range is 0 to 10 VDC. When configured as current inputs the full range is 0 to 20mA and the input resistance is 250  $\Omega$ . When configured as an RTD input, the range varies based on the RTD Probe. Supported Probe types include Pt100, Pt1000, Cu10.

**NOTE:** 0 to 20mA AI's accommodate standard 4 to 20mA instrumentation current loop signals.

### 3.3.2.4 Analog Outputs

Analog Outputs produce voltage or current output signals. When configured as voltage outputs the full range is 0 to 10 VDC at 1mA maximum. When configured as current outputs the full range is 0 to 20mA with a maximum load resistance of 450  $\Omega$  at 12V.

For all models except the ZZ-4AO-2, the 0-20mA output circuit is comprised of an open collector sinking output. This means that an external supply will be required to properly setup the current loop. This type of circuit sinks the current to a common ground, which will require the use of either a differential input type or an isolator in-between the output and input circuits.



**NOTE:** 0 to 20mA AO's accommodate standard 4 to 20mA instrumentation current loop signals.

### 3.3.3 I/O Wiring

#### 3.3.3.1 DI Wiring

The following diagram shows typical connection wiring for various Digital Inputs:




Figure 12 Typical Digital Input Wiring for Various Input Devices (ZZ-4DI4D0-DCT Expansion Module)

**NOTE:** No external power supply wiring is required for Expansion Modules.

#### 3.3.3.2 DO Wiring

The following diagram shows typical connection wiring for modules featuring **sourcing (PNP) drivers**:




Figure 13 Typical Digital Output Wiring for Sourcing Outputs (ZZ-4DI4D0-DCT Expansion Module)

The following diagram shows typical connection wiring for modules featuring **relay drivers**:




Figure 14 Typical Digital Output Wiring for Relay Outputs

The following diagram shows typical connection wiring for modules featuring **sinking (NPN) drivers**:




Figure 15 Typical Digital Output Wiring for Sinking Outputs (ZZ-4DI4D0-DCT1 Expansion Module)

### 3.3.3.3 AI Wiring

The following diagram shows typical connection wiring for Analog Inputs (both current and voltage inputs):




Figure 16 Typical Analog Input Wiring (ZZ9D-NA-MR Base Module)

The following diagram shows typical connection wiring for Analog Inputs configured as voltage signals:




Figure 17 Typical Analog Input Wiring (Voltage)

### 3.3.3.4 AO Wiring

The following diagram shows typical connection wiring for Analog Outputs. When used as current outputs (0-20mA setting), the analog outputs in the Zlinx base and expansion modules (except ZZ-4AO-2) are sinking type. When used as voltage outputs (0-10Vdc), analog outputs from all the modules are sourcing type.

Current output Configuration (all Zlinx Gen II modules except ZZ-4AO-2):

An external voltage source is necessary and should be connected as shown below:




Figure 18 Typical Analog Output Wiring (ZZ9D-NA-MR Base Module)

Current output Configuration (for ZZ-4AO-2):




Figure 19A Typical Analog Output Wiring (ZZ-4AO-2 Module)

When configured as a voltage output, the analog outputs are of sourcing type. The following diagram shows typical Analog Output Wiring for Sourcing drivers:

Analog output connection for Sourcing drivers:




Figure 20 Typical Analog Output Wiring for Sourcing Outputs

Voltage output Configuration (all Zlinx Gen II modules):

The following diagram shows typical Analog Output Wiring for Sourcing outputs configured as voltage signals:




Figure 21 Typical Analog Output Wiring for Sourcing Outputs (Voltage)

### 3.3.3.5 RTD Wiring

The following diagram shows typical connection wiring for RTD inputs:




Figure 22 Typical RTD Input Wiring

### 3.3.4 Modbus I/O Addressing

Zlinx Wireless I/O modules can be configured to operate as wireless Modbus nodes. The Modbus device should be connected to the Modbus radio modem. In Modbus mode messages are sent across the wireless link from a Modbus radio-modem to the Zlinx Wireless I/O and from the Zlinx Wireless I/O to the Modbus radio-modem. Digital and Analog Input information from the Zlinx Wireless I/O inputs is stored in the Zlinx Wireless I/O memory and then sent across the link to the Modbus modem. Digital and Analog Output information is sent from the Modbus modem to the Zlinx Wireless I/O, stored in its memory, and then sent to the outputs.

To use Modbus mode successfully, an understanding of the Zlinx Wireless I/O memory map assignments is necessary.

What is a Modbus Map?

A Modbus Map is simply a list for an individual slave device that defines:

- What the data is (ex. pressure or temperature readings).
- Where the data is stored (which tables and data addresses).
- How the data is stored (data types, byte and word ordering).

Some devices are built with a fixed map that is defined by the manufacturer, while other devices allow the operator to configure or program a custom map to fit their needs.

Modbus function codes supported:

- Function 1: Read DO Status
- Function 2: Read DI's
- Function 3: Read AO Status
- Function 4: Read AI's
- Function 5: Write to Single DO (firmware v2.0 or higher)
- Function 6: Write to Single AO
- Function 15: Write to Multi DO's

Messages sent between Zlinx Wireless I/O and a Modbus modem use Modbus memory addresses to specify what type of information is being sent and where it is stored. In the Modbus addressing scheme each type of I/O (DO, DI, AI, and AO) is stored in a different section of the memory.

I/O Type	Modbus Memory Address
DO	00001 to 00112
DI	10001 to 10112
AI	30001 to 30112
AO	40001 to 40112

Figure 23 I/O Memory Areas Table

Within these sections, addresses are reserved for all Zlinx Wireless I/O modules that may be used.

Module	Memory Range
Base	n0001 to n0016
Expansion 1	n0017 to n0032
Expansion 2	n0033 to n0048
Expansion 3	n0049 to n0064
Expansion 4	n0065 to n0080
Expansion 5	n0081 to n0096
Expansion 6	n0097 to n0112

Figure 24 Module I/O Addressing Table

**NOTE:** In the table “n” is a single digit between 0 and 4.

The following examples show how the addressing works:

Example 1: To turn on the second Digital Output (DO2) on the Base Module, the Modbus modem sends a message placing a logic 1 in memory location 00002.

Example 2: To cause Expansion Module 3 to output a specified voltage on AO1, the Modbus modem sends a message to set the register at Modbus address 40049 to the appropriate value. Refer to “Appendix I: Convert Voltage to DAC” for the information on how to convert voltages to DAC.

A list of all Modbus address assignments for all Zlinx Wireless I/O points is shown in Appendix D: “Modbus I/O Assignments”. Several important points about this list should be noted:

- ❑ Some addresses are listed but not implemented in current versions of Zlinx Wireless I/O hardware. Refer to “Appendix D: Modbus I/O Assignments”.
- ❑ Some addresses are reserved for internal Zlinx Wireless I/O use.
- ❑ Some addresses are reserved for future use.
- ❑ 40000 series addresses store Analog Output data AND Counter data when Digital Inputs are configured for Counter operation. For each module, the first eight memory locations are assigned to AO data and the next four locations (7 for Base and 2 for Expansion Modules) are assigned to Counter data.

**NOTE:** For more information on Counters, see section 3.3.5 “Modbus Counters”.

- ❑ If a Modbus device communicating with Zlinx Wireless I/O tries to send to or receive from a memory address not implemented by the hardware in use, the Zlinx Wireless I/O replies with an exception response.

**NOTE:** “Appendix D: Modbus I/O Assignments” of this manual contains a list of Modbus I/O assignments for the Zlinx Wireless I/O.



### 3.3.4.1 Function Field and Modbus I/O Addressing

#### Modbus Function Code

The function code in the Master device query tells the addressed slave device what kind of action to perform. The data bytes contain any additional information that the slave will need to perform the function. For example, function code 03 will query the slave to read holding registers and respond with their contents. The data field must contain the information telling the slave which register to start at and how many registers to read.

#### Modbus I/O addressing

The Modbus protocol allows for two types of I/O addressing: implied and extended. Implied addressing uses the function code to determine the I/O address and only requires the minimum address; i.e. 40012 = 0x0C, the *4nnnn* is implied.

The extended address contains the entire I/O address; i.e. 40012 = 0x9C4C.

Another example:

Using holding register 40108 to address a DAC or analog output. The function code field already specifies a “holding register” operation. Therefore the “*4nnnn*” reference is implicit. Holding register 40108 is addressed as register 0x006B (107 decimal).

The B&B Zlinx series of remote I/O devices uses the implied I/O addressing method. If your device is sending the full extended I/O address, an error will occur.

### 3.3.5 Modbus Counters

#### Base Modules

In Modbus mode a Base Module supports two Digital Inputs as counters:

- Frequency.
- Accumulators.

There are four accumulator registers on only the Base Module which hold accumulators information – two for each Digital Input.

Accumulator most significant count register 400*nn* displays the respective count from 0 to 9999.

Accumulator least significant count register 400*nn* displays the respective count from 0 to 9999. This will increment the most significant count when it rolls over from 9999 to 0.

Time to save totals register counts down the number of seconds (from 300-0 seconds) until the Accumulators are saved internally.

#### Expansion Modules

In Modbus mode Expansion Module supports two Digital Inputs as frequency.

There are two frequency registers on each module which hold frequency information – one for each Digital Input. Register addresses for frequency will be found at 40*nnn*, (where “*n*” is a single digit between 0 and 9).

**NOTE:** For more information see “Appendix D: Modbus I/O Assignments”.

#### Accumulators

A typical electric water meter will generate a pulse per 1/10 gallon of water flowing through it. This type of application is best used with the Modbus accumulators. The accumulators are broken down into two registers, most significant count and least significant count. Both accumulators have a full count of 9999. When the least significant count exceeds 9999, it will increment the most significant count giving a total system count of 99,999,999.

The accumulators reside in the holding register map and maybe written to in order to reflect what a typical water meter may have displayed on its display. There is also a holding register associated with the accumulators that indicates the number of seconds before the accumulators are saved. The accumulator data is saved every ~5min.

## Frequency

Flow meters typically generate a frequency based on the amount of fluid flowing through the sensor. The flow and respective frequency varies on the manufacture and sensor. The frequency measurement is located in a separate Modbus holding register and may not be written to. The frequency register is formatted in cycles/sec and requires the user to convert the frequency to respective flow units

## 3.4 Accessories

### 3.4.1 LED Indicators

**Base Modules** have four LED indicators: a Power LED, an RSSI LED, a Wireless Data LED, and a Local Bus Data LED.

**Expansion Modules and Configuration Boxes** have two LED's: a Power LED and a Local Bus Data LED.

#### 3.4.1.1 Power LED

The **Power** LED illuminates (red) immediately on power up indicating that AC or DC power is present on the power supply terminals.

#### 3.4.1.2 RSSI LED

The **RSSI** LED provides an indication of the signal strength of the received radio signal. The color of the LED indicates whether the signal is weak, OK, or strong. The table below explains the colors of RSSI LED:

LED Color	Signal Strength
Off	No signal
Red	Weak
Yellow	OK
Green	Strong

Figure 25 RSSI LED Status Table

**NOTE:** Data can be sent and received for Weak, OK, and Strong Signal.

#### 3.4.1.3 RF Data LED

The **RF Data** LED blinks green when data is being transmitted or received on the radio link. When the LED is off no data is being transmitted or received.

#### 3.4.1.4 Bus LED

The **Bus** LED blinks green when data is being transmitted or received on the local bus connection. When the LED is off no data is being transmitted or received.

**NOTE:** If communications is not established within a preset number of retries (default is 10) the RF Data and Bus LED's blink alternately to indicate a loss of communications.

## 3.4.2 Antennas

Base Modules operating in the 900 MHz band come equipped with 6.5-inch folding rubber duck antennas (ZZ9D-ANT1) that screw onto the reverse SMA connector on top of the case. Base Modules operating in the 2.4 GHz band come equipped with 4.25-inch, folding rubber duck antennas (ZZ24D-ANT1). Higher gain antennas may be connected to extend the range.

### 3.4.3 Connectors

Zlinx Wireless I/O Base and Expansion Modules feature connectors for connecting field I/O wiring and plugging together Zlinx Wireless I/O modules (local bus). In addition, Base Modules include connectors for connecting an antenna and power supply. Configuration Boxes include a serial connector for connecting to a PC COM port or if using the ZZ-PROG1-USB then a USB connector is provided for connecting to the PC.

#### 3.4.3.1 Antenna Connector

Base Modules have a reverse SMA antenna connector mounted on the top edge of the enclosure.




Figure 26 Top View of a Base Module

#### 3.4.3.2 Power Supply Connector

The **Power Supply** connector (Base Modules only) is a two-position removable terminal block located on the top of the unit. Terminal spacing is 3.5 mm. The terminal block accepts solid and stranded wires from 28 AWG to 16 AWG. **Please check polarity marking in Figure 26.**

**NOTE:** Refer to section 4.1.1 "Power Supply Requirements" for more information.

The Configuration Box and all Expansion Modules receive power from the Base Module via the local bus connector.

#### 3.4.3.3 Serial Port Connector

The **Serial Port** connector (Configuration Box only) is a DB-9F (female) connector which comes on the ZZ-PROG1. The Configuration Box is configured as a DCE. For programming, a standard straight-through serial cable with DB-9F on one end and DB-9M on the other is required. (Part No. 9PAMF6 recommended)




Figure 27 DB-9 Female Serial Port Connector with Pin-out

#### 3.4.3.4 Local Bus Connectors

The **Local Bus** connectors are included on Base, Expansion, and Configuration Boxes. These connectors are dual row, 14 pin (2 mm spacing) connectors, male on one side of the module and female on the other (except Base Modules which don't have left-side connector and Configuration boxes which don't have right-side connector). Modules are plugged together to supply power and facilitate communication between modules.

When adding an Expansion Module to a Base Module the male connector on the Expansion Module plugs into the female connector on the Base Module. The second Expansion Module plugs into the first, and so on, up to a maximum of six Expansion Modules.



Figure 28 ZZ-TB1 Accessory Kit Contents

The Configuration Box should be installed on the right hand side of the system.

### 3.4.3.5 I/O Connectors

I/O connectors for Base and Expansion Modules are removable (plug in) screw terminal blocks located on the front of the unit. Terminal spacing is 3.5 mm. Depending on the specific model, the number of terminals may vary. The maximum is 16 terminals (two 8-terminal blocks).

Extra terminal blocks are available in an accessory kit (ZZ-TB1). The kit includes:

Item	Quantity
2-position terminal block	2
4-position terminal block	2
8-position terminal block	2
Shroud cover	1

Figure 29 ZZ-TB1 Accessory Kit Contents

**NOTE:** For information on replacement parts refer to "Appendix B: Product Specifications".

### 3.4.4 Mounting Hardware

Zlinx Wireless I/O modules can be DIN rail mounted. The DIN mounting clip and spring is included on each module.



Figure 30 DIN Clip with Spring on a Zlinx Wireless I/O Module

## 4.1 Zlinx Wireless I/O Installation

### 4.1.1 Power Supply Requirements

Zlinx Wireless I/O systems can be powered from DC or AC power sources. No supply is included since the power rating of the supply will depend on the total power requirements of all modules used in the system.

**NOTE:** "Appendix B: Product Specifications" contains a listing of power requirements for all Zlinx Wireless I/O modules.

If an AC power supply is to be used, it must be 24VAC.

If a DC power supply is to be used, it must be 10-40VDC.

**NOTE:** 110/220/240 VAC mains power must NOT be connected to any input terminal on Zlinx Wireless I/O modules.

### 4.1.2 RF Site Considerations

When installing any radio equipment it is important to give careful consideration to the installation location and the surrounding area. Radio transmission and reception is affected by absorption, reflection and refraction of the radio signals. These factors are determined by the distance between the transmitting and receiving antennas, the type, position and amount of obstructions, antenna heights, frequency band and RF power used, and other factors.

There are several ways to optimize the RF environment to ensure satisfactory performance. A partial list of these follows:

- Select the Zlinx Wireless I/O radio option that provides sufficient power for your application. Lower frequencies travel farther and are less affected by absorption in materials. Higher power levels generally provide greater penetration through objects.
- Select installation locations that come as close as possible to providing LOS access between Base Modules.
- Avoid installation locations where metal objects may block, reflect, refract or cause multipathing of radio frequencies. In some cases reflections may enhance reception but in others it can cause problems. Some experimentation may be necessary.
- Select installation locations to increase antenna heights.
- Select equipment enclosures made of materials that minimize RF attenuation.
- Avoid locations with other radio equipment that may cause interference.
- In some cases alternate types of antennas (more directional) or remote antenna mounting (outside of enclosures or at a higher elevation) may be required.

Most importantly, some research and testing of the proposed installation location(s) should be carried out. Sometimes small changes in location can make a significant improvement to coverage. For RF information see section 2.5 "Radio Frequency Basics".

### 4.1.3 Zlinx Wireless I/O Mounting

Zlinx Wireless I/O modules are DIN rail mountable. Additional ZZ-DIN1 mounting kits can be purchased for replacement. Each kit includes a DIN clip and spring and four spare screws for the Zlinx Wireless I/O enclosure.

**NOTE:** Refer to "Appendix B: Product Specifications" for more information on accessories and their replacements.

## 4.2 Computer System Requirements

The Zlinx Manager software requires the following computer hardware and operating systems:

- ❑ A PC with one serial port available between COM1 and COM16. Serial port is necessary if using ZZ-PROGKIT or ZZ-PROG1. In the case of using ZZ-PROG1-USB it is necessary to have a PC with a USB port.
- ❑ Windows 7 or XP (Home or Professional with SP1 or SP2), Windows 2000 SP4, Vista 32 bit.

## 4.3 Installing Zlinx Wireless I/O Software

To install the Zlinx Manager software:

1. Insert the CD included with your Zlinx Wireless I/O product into the CD ROM drive of your PC.
2. The installation should launch automatically. If not:
  - a. Click **Start** on the Task Bar and select **Run**.
  - b. Type in `[drive]:\ZlinxMgr.exe`
3. Follow the prompts to install the software.

When installation is complete Zlinx Manager, and PDF files containing this manual, Quick Start Guides, manuals for other Zlinx Wireless I/O products, and Uninstall shortcut are accessible from the Windows Start menu.

**NOTE:** If the CD is not shipped with the product you can download the software at <http://www.bb-elec.com>.

## 4.4 Installing ZZ-PROG1-USB Drivers

If using the ZZ-PROG1-USB as the configuration kit, follow the steps below to install the USB Driver:

1. Drivers are included on the Compact Disk included with the kit. These drivers will also be copied onto the same location that the Zlinx Manager Software is installed.
2. Simply connect the device to an available USB port on the PC.
3. The "Found New Hardware Wizard" will guide you through the installation process. The drivers are not available via Microsoft Windows Updates.
4. When prompted to connect to Windows Updates to search for drivers, select "No, not at this time" and follow the instructions for installing from the CD or the location on the hard drive.
5. When the driver software is installed, the ZZ-PROG1-USB will show up in Windows Device Manager as the next available COM port labeled "Model ZZ-PROG1-USB". The "Model ZZ-PROG1-USB" will also be listed under the USB Controllers.
6. To uninstall the drivers, follow the instructions contained in the uninstall, "USB Serial Uninstall.pdf", file.

## 4.5 Connecting Zlinx Wireless I/O to a PC

To connect Zlinx Wireless I/O to a PC:

1. With power disconnected from the Base Module connect any required Expansion Modules to the Base Module. The male local bus connector on the first Expansion Module plugs into the female connector on the Base Module. The second Expansion Module plugs into the first, etc.
2. With power disconnected from the Base Module, plug the ZZ-PROG1 (or ZZ-PROG1-USB) Configuration Box into the Base Module.




Figure 31 A PC, Configuration Box and Base Module

3. Connect the PC serial port to the Configuration Box using a straight-through serial (9 pin) cable or USB cable if using the ZZ-PROG1-USB module.
4. Re-apply power to the Zlinx Wireless I/O Base Module. The Power LED's should light up.

## 4.6 Starting Zlinx I/O Configuration

To Start Zlinx Manager:

1. From the Windows Start menu, start the **Zlinx Manager** software.

Zlinx Manager Screen opens offering navigation to Zlinx Manager or Radio Modem Manager.

2. Click on the **Zlinx I/O**.
3. To go to the configuration window click on the **Zlinx I/O Configuration**. Zlinx I/O Firmware Updater, Zlinx I/O Monitor are also started from this window.

The Zlinx Wireless I/O splash window appears briefly, followed by the discovery window.

4. The Connection drop down list defaults to **Automatic** discovery. The software scans through COM ports looking for Zlinx Wireless I/O devices. The scan starts with the most recently used serial port in which a device was found.






Figure 32 Discovery Window

During the scan the Progress box displays information about the scanning process. If a device is not found at the most recently successful port it continues to scan through COM ports 1 to 16. The bar graph near the bottom of the window indicates progress.

5. If the device is not found the Progress box displays:

*"The device was not found on any serial port."*

- a. Check the power supply and serial cable connections.
- b. Click the **Connect** button. The connection process will be repeated and the device should be found.

6. If Automatic connection is not desired, a particular COM port (1 to 16) can be specified:

- a. Select the COM port number from the Connection drop down list.
- b. Click the **Connect** button to initiate the connection process.

**NOTE:** Clicking the **Stop** button stops the module discovery process.

7. If the device is found, the Zlinx I/O Configuration window opens.




Figure 33 Zlinx Manager

The Zlinx I/O Configuration window contains:

- ❑ File and Help menus.
- ❑ Three tabbed panes: Information, Configuration, and Input/Output.
- ❑ A Help sidebar containing information and hints related to the current tab. If the sidebar is not visible enable it by going to **Help > Sidebar**.
- ❑ A graphic display of the Base and Expansion Modules discovered.
- ❑ A Status bar (at the bottom) showing the COM port and communications parameters: baud rate, parity, data bits, stop bits and flow control.
- ❑ An **Update** button used to save configuration parameters to the modules.
- ❑ An **Exit** button.

---

## 4.7 Zlinx I/O Configuration Options

### 4.7.1 Information Tab

The Information tab displays a tree structure listing:

- Base and Expansion Modules detected and their model numbers.
- Generation number.
- Firmware version number for each module.
- Hardware version number for each module.
- Radio firmware version number for the Base Module.
- Radio hardware version number for the Base Module.

### 4.7.2 Configuration Tab

The Configuration tab contains fields that allow configuration of:

- Wireless (Radio) parameters: Transmit Power, Channel Number, Network Identifier and Repeater Mode.
- Communications Modes: Peer-to-Peer Master, Peer-to-Peer Slave, Modbus and related parameters.
- Parameters corresponding to the chosen communication mode.

### 4.7.3 Input/Output Tab

The Input/Output tab contains:

- A tree structure listing input and output types for each module.
- Input and output configuration options.

## 5. Configuration & Operation

**Zlinx I/O Configuration** software is used to configure Zlinx Wireless I/O hardware. Using Zlinx I/O Configuration, the system can be configured to operate in Peer-to-Peer (wire-replacement) or Modbus modes receiving Modbus commands and data from a Modbus wireless modem. Digital Inputs can be configured to operate in Discrete (on/off) or Counter modes, and Analog Inputs and Outputs are configurable for voltage or current loop operation.

### 5.1 Configuring Zlinx Wireless I/O

To enable the features described below (except Monitor):

1. Start Zlinx Manager.
2. Choose **Zlinx I/O Configuration** (See Section 4.5 for more details).
3. The features are enabled and parameters for them are set in **Configuration** tab.

Zlinx Wireless I/O modules can be configured to operate as wireless Modbus nodes or as wire replacement links in Peer-to-Peer mode. Wireless configuration options are the same for either mode.

#### 5.1.1 Wireless Settings

Zlinx Wireless I/O Base Modules can be configured for operation with different transmitter output power. They can also be configured to operate on several different radio channels. This allows multiple Zlinx Wireless I/O systems to operate in the same area without interference. The number of different systems can be further increased by configuring a unique Network Identifier (which selects the frequency hopping sequence). Base Modules also can be used as repeaters, to extend the range of a system. Over-the-air (OTA) data rate can also be adjusted to increase range. A lower OTA data rate will increase the effective range of the radio, but will also increase the total throughput time.

Firmware Version 3.19 and higher supports the following features

Base Module	Transmit Power Selectable	RF OTA Data Rate	AES Encryption
SR	YES	NO	128 BIT
MR	NO	NO	NO
LR	YES	YES	256 BIT
LR-AU	YES	YES	128 BIT
ZZ8D-xx-LR (868 MHz)	YES	NO	128 BIT

To configure Wireless settings:

1. Select the **Configuration** tab.




Figure 33 Wireless Area Configuration Tab

2. In the **Transmit Power** drop down list, select your desired output power. Increasing this value will increase maximum range and electrical power consumption. Setting this value too high may violate regulatory transmission limits for your region and could cause harmful interference to other devices.

Base Module	Power Selections	Factory Default
ZZ24D-xx-SR	10mW, 16mW, 25mW, 40mW, 63mW	63mW
ZZ9D-xx-MR	Not Supported	100mW
ZZ24D-xx-MR	Not Supported	50mW
ZZ8D-xx-LR	1mW, 23mW, 100mW, 159mW, 316mW	316mW
ZZ9D-xx-LR	1mW, 10mW, 100mW, 500mW, 1000mW	1000mW
ZZ9D-xx-LR-AU	1mW, 10mW, 100mW, 500mW, 1000mW	1000mW

3. Set the **Channel Number** field to match the channel used by the device with which it will communicate.
  - a. If that device is another Zlinx Wireless I/O Base Module, set the Channel Numbers the same when configuring each of them.
  - b. If the device is a Modbus radio modem, the modem must be configured by using Zlinx Radio Modem Configuration to match the Base Module's Channel Number.
  - c. Each Zlinx Wireless I/O radio type uses a different Channel Number range. Modbus radio modems should be configured using Radio Modem Configuration depending on the radio type. The table below shows these ranges and commands in hexadecimal values:

Type/Range	Base Module Channel Number Range
Short Range (SR)	0x0C to 0x17
Medium Range (MR)	0x00 to 0x06
ZZ8D-Nx-LR	Single Channel
ZZ9D-Nx-LR-xx	0x00 to 0x09

Figure 34 Radio Types, Channel Numbers

**NOTE:** The default value of the Channel Number field for SR radios is 0x0C; the default for MR and ZZ9D-Nx-LR-xx radios is 0x00.

4. Set the **Network Identifier** field to match the Identifier used by the device with which it will communicate.
  - a. If that device is another Zlinx Wireless I/O Base Module, set the Network Identifiers the same when configuring each of them.
  - b. If the device is a Modbus radio modem, the modem must be configured by using Zlinx Radio Modem Configuration to match the Base Module's Network Identifier.
  - c. Each Zlinx Wireless I/O radio type uses a different Network Identifier range. The table below shows the channel number ranges in hexadecimal values.

Type/Range	Base Module Network Identifier Range
Short Range (SR)	0x00 to 0xFF
Medium Range (MR)	0x10 to 0xFF
ZZ8D-Nx-LR	0x00 to 0xFF
ZZ9D-Nx-LR-xx	0x11 to 0xFF

Figure 35 Network ID Value Table

The default value of the Channel Number field for SR radios and ZZ8D-Nx-LR radios is 0x00; the default for MR radios is 0x10 and for ZZ9D-Nx-LR-xx radios is 0x11.

- d. If the device is a Modbus radio modem, for MR and ZP9D-Nx-LR-xx radio modems set the destination address to 0xFFFF using the Zlinx Configuration Manager.

5. Select the **Repeater** checkbox if the Zlinx Wireless I/O Base Module is to be used as a repeater, re-broadcasting I/O data received in Modbus or Peer-to-Peer modes.

The default value of the Repeater field is unchecked.

**NOTE:** Repeater Mode can only be implemented on the Medium Range (MR) and ZZ9D-Nx-LR-xx Base Modules. The Repeater checkbox is not available on Short Range (SR) or the ZZ8D-Nx-LR Base Modules.

6. The following **AES Encryption** options are available.
- a. Disabled – Select this if you do not desire to encrypt your network.
    - i) Check the Disable option and press the Update button on the bottom of the screen.
  - b. Hexadecimal Key – Select this if you desire to use a hexadecimal stream to encrypt your network.
    - i) On the first base module, check the Hexadecimal Key option. Press the Generate Random Key button. A random hexicecimal key will appear in the Key Box. (You can type your own hex key into the Key Box, but it is recommended that you use the random generator). This key will not be stored in the module until the Update Button on the bottom of the screen is pressed. Do not press the update button yet.
    - ii) Copy this key into a text file. You will need it to configure the key in the downstream base module or radio modem.
      - (1) Highlight the characters displayed in the Key Box using your mouse and left mouse button.
      - (2) When all the characters are highlighted, press “CTRL” and “C” on your keyboard. This copies the characters to the Windows clip-board.
      - (3) Open Note Pad and press “CTRL” and “V” on your keyboard. The characters will appear. Save this file and use it to configure the key in the downstream module.
    - iii) Press the Update button on the bottom of the screen.
  - c. Text Key – Select this if you desire to use a text sequence to encrypt your network.
    - i) On the first base module, select the Text Key option. Type text into the key box. The text is limited to 128 or 256 bits (as applicable). If your text is not long enough, the remainder will be filled in with zeros when it is converted to ASCII by the software. The ASCII conversion happens automatically. If you desire, you can view the ASCII code by selecting the Hexidecimal Key option. The ASCII code will be displayed.
    - ii) Copy and save your text stream into a file in the same manner as 6.b.ii above.
    - iii) Press the Update button on the bottom of the screen.
  - d. Use Existing Key – Select this option to use the key that is stored in the base module.
  - e. To update the key in a downstream base module:
    - i) Hexadecimal key:

- (1) Select Hexidecimal Key
  - (2) If a key is displayed in the Key Box, delete it
  - (3) Open the file generated in 6.b above.
  - (4) Copy the key by using your mouse and left click to highlight all of the characters. Press the “CTRL” and “C” key on your keyboard.
  - (5) With your mouse, left click in the Key Box. On your keyboard, press “CTRL” and “V”.
  - (6) Press the Update Button at the bottom of the screen.
- ii) If you are using a Text key, the key can be updated in two ways:
- (1) Copy Text Key
    - (a) Select Text Key
    - (b) If a key is displayed in the Key Box, delete it.
    - (c) Open the file generated in 6.c above
    - (d) Copy the key by using your mouse and left mouse button to highlight all of the characters. Press CTRL” and “C” on your keyboard.
    - (e) With your mouse, left click in the Key Box. On your keyboard, press “CTRL” and “V”.
    - (f) Press the Update Button at the bottom of the screen.
  - (2) Type Text Key
    - (a) Select Text Key
    - (b) If a key is displayed in the Key Box, delete it.
    - (c) Type in the key you generated in 6.c above.
    - (d) Press the Update Button at the bottom of the screen.

## 7. Configuring AES Encryption on a Zlinx Radio Modem






Figure 36 Zlinx Radio Modem Encryption

- a. Figure 36 shows the Zlinx Radio Modem configuration screen.
- b. Click the ATKY Set button (for SR and LR-868 models, the ATEE command also needs to be set to 1). The Set Hex String box will appear. Copy the key generated in 5.a or 5.c into the box.

**8. Configure RF Data Rate**

- a. LR and LR-AU base modules allow you to configure the over-the-air RF Data Rate. Using 9600 baud on these modules increases the effective range of the module.
  - i) This data rate may be configure for 9600 baud or 115200 baud.

**5.1.2 Modbus Mode Settings**

When configured as a wireless Modbus node, Zlinx Wireless I/O communicates with a Zlinx Wireless Modbus Modem and provides remote I/O functionality. Zlinx devices are Slave nodes and can not be configured as Modbus Masters.

**NOTE:** Refer to "Appendix E: Zlinx Wireless I/O Models and Features" for a list of which Zlinx Wireless I/O Modbus modems are compatible with which Zlinx Wireless I/O Base Modules.

When the Zlinx Wireless I/O receives a Modbus message to write "1" to a discrete output (0nnnn addresses in its memory map), the Zlinx Wireless I/O module turns on its corresponding Digital Output. If a message containing holding register data is received (4nnnn addresses in its memory map), the Zlinx Wireless I/O module converts the value to a voltage or current signal on the corresponding Analog Output.




Figure 367 Modbus Mode

Digital and analog signals applied to the Zlinx Wireless I/O module's input terminals are converted to Modbus messages to be sent back to the radio modem. Digital Inputs are stored as  $1nnnn$  (coil) addresses; Analog Inputs are converted to 12 bit binary values and stored in  $3nnnn$  (input register) addresses.

To configure the Zlinx Wireless I/O for Modbus mode:

1. Select the **Configuration** tab.
2. Select the **Modbus** option button.
3. In the **Modbus Address** box, type the Modbus address to be used.

The allowable range of Modbus addresses is from 1 to 247. The default Modbus address is 1.

4. Set the value for the Communication failure timeout (in seconds). If within the predefined timeframe no data is coming from Modbus Master (Modbus Radio Modem), the Zlinx I/O device perceives it as a communication failure




Figure 378 Configuration Tab (Default values are with encryption disabled and maximum radio power)

### 5.1.3 Peer-to-Peer Mode Settings

In Peer-to-Peer mode digital and analog signals can be transferred in both directions across a Zlinx Wireless I/O link. For successful communication both Base Modules must be the same model and all Expansion Modules must be complimentary (e.g. DI to DO, AI to AO) and arranged in the same order on the Local Bus. One is configured as Peer-to-Peer Master and other is configured as Peer-to-Peer Slave. It does not matter which one is configured as Master. Additionally, Peer-to-Peer Master address MUST match the Peer- to-Peer Slave address (1-255).

The user can invert logic of all Digital Outputs when such option is enabled. The feature applies to Base and Expansion Modules. With such settings if the signal coming to the affected Digital Output is ON (low), the Digital Output will show OFF (high).

*NOTE: For more information on Invert Output option see section 5.1 "Configuring Zlinx Wireless I/O".*

#### 5.1.3.1 Peer-to-Peer Master

To configure the Zlinx Wireless I/O Base Module for Peer-to-Peer Master Mode:

1. Select the **Configuration** tab.
2. Select the **Peer-to-Peer Master** option button.




Figure 389 Peer-to-Peer Master Configuration

3. Set the Peer-to-Peer Master address from 1 to 255. Please note the Peer-to-Peer Slave address must also match.
4. The **Polling Rate** box contains the number of seconds between polls by the Master. The default value of 1 second is usually satisfactory. The range of values is 0 seconds to 20 seconds. If the I/O points are not updating properly, try increasing the value.

**NOTE:** "0" causes the firmware to transfer data as fast as possible with no delays..

5. The **Retry Count** box contains the number of attempts that will be made to communicate with the Slave device before the module indicates communication has been lost. Lost communication is indicated by the RF Data and Bus LED's blinking alternately. The default value of 10 is usually satisfactory. The range of values is 10 to 255.

### 5.1.3.2 Peer-to-Peer Slave

To configure the Zlinx Wireless I/O Base Module for Peer-to-Peer Slave Mode:

1. Select the Configuration tab.
2. Select the Peer-to-Peer Slave option button.

3. Set the Peer-to-Peer Slave address from 1 to 255. Please note the Peer-to-Peer Master address must also match.
4. Communication Failure Timeout. If within the predefined timeframe no data is coming from Peer-to-Peer Master, Slave interprets it as a communication failure.




Figure40 Peer-to-Peer Slave Configuration

### 5.1.4 Input/Output Settings

Digital Inputs/Outputs and Analog Inputs/Outputs on Zlinx Wireless I/O modules are configured from the Input/Output tab of the Zlinx Manager. The first two Digital Inputs on any module can be configured as Discrete inputs or Counter inputs. Any additional Digital Inputs operate as Discrete inputs only. Counter operation is only functional when the Zlinx Wireless I/O is set up in Modbus mode. Analog Inputs and outputs can be configured for voltage or current loop operation.

To configure Digital and Analog I/O:

1. Select the Input/Output tab.

An input tree appears listing all Base and Expansion Modules in the system and the inputs/outputs available on them.




Figure41 Digital Input Configuration

2. Select the Digital Input to be configured.
3. Select Discrete or Counter (for the first two inputs only). Setting the Digital Mode of either of the first two DI's to Counter mode sets both DI's on that module to the same mode.

**NOTE:** See section 3.3.5 "Modbus Counters".

4. Select the Digital Output to be configured.
5. Select Invert Output option.




Figure42 Digital Output Configuration

6. Select the Analog Input to be configured.
7. Select the required Analog Mode (0 to 10 VDC or 0 to 20 mA).

**NOTE:** Setting the Analog Mode of one AI or AO sets all AI's and AO's on that module to the same mode.




Figure43 Analog Input Configuration

8. Select the Analog Output to be configured.




Figure 3944 Analog Output Configuration

9. Select the required Analog Mode (0 to 10 VDC or 0 to 20 mA).

If RTD module is present:

1. Select the Input/Output tab.

- a) An input tree appears listing all Base and Expansion Modules in the system and the inputs available on them.




Figure 45 RTD Input Configuration

- b) Select the RTD to be configured.
- c) To increase speed, RTD channels may be turned on or off. If nothing is connected to the RTD channel, then uncheck the Channel Enabled option.
- d) Select the RTD type as Pt100, Pt1000, Cu10 depending on your RTD type.
- e) Select if you have wired a 2, 3, or 4 wire RTD probe to the input module.

**NOTE:** Refer to “Appendix F: RTD Module” for more information on RTD module.

### 5.1.5 Exception Reporting

This feature provides the ability of reporting possible problems on devices. It is applied for both Base and Expansion Modules, and available only for Modbus mode.

**NOTE:** Base and only first Expansion Module next to the Base Module can generate an exception.

For Analog Inputs exception reports will be periodically sent if an input goes outside the low and high thresholds. Once an input enters the exception state, it must be greater than the low threshold plus the dead band or less than the high threshold minus the dead band in order to stop being in the exception state.

In general, the Modbus protocol does not support exception reporting. In a typical Modbus system the Modbus Master sends a request to a respective Slave device and the slave device will respond with an ACK. Typical Slave data does not contain I/O addressing data. Any data sent from the Slave to the Master, without the Master first requesting it, will be ignored by the Master. Therefore, it’s understood that the exception features will require the end user to use a custom driver to capture the exception data.



Analog Exception errors are generated when user-defined High or Low limits are exceeded. If an Analog Input value rises above the High limit, an exception is generated and immediately sent out. Data is updated and retransmitted based on the Exception Retransmit timer. Exception is transmitted in the timeframe predefined by the user within the allowable range. If the Exception reporting timeout is set to zero, the exception is sent only once to the Modbus Master.

- ❑ Analog Value > HIGH LIMIT = Exception Error.

The High exception error is cleared when the Analog Input value falls below the high limit – the dead band value.

- ❑ Analog Value < (HIGH LIMIT – DEAD BAND) = Exception Error Cleared.

If an Analog Input value falls below the LOW limit, an exception is generated and immediately sent out. Data is updated and retransmitted based on the Exception Retransmit timer.

- ❑ Analog Value < LOW = Exception Error.

The Low exception error is cleared when the Analog Input value rises above the low limit + the dead band value.

- ❑ Analog Value > (Low + DEAD BAND) = Exception Error Cleared.

### 5.1.5.1 Sample Modbus Exception Packet

Exception Modbus packets do not follow the typical Modbus protocol. The Base Module is a Slave device and in a typical system, slave devices do not generate outgoing requests. When the Base or the exception Expansion Module (1st module next to the Base Module) generates an exception, the Base Module will generate a Modbus packet that emulates a “Master Poll”. The exception packet is sent to the Master and does not require an ACK.

### 5.1.5.2 Digital Exception Format

#### Base Module DI exception

01 02 00 01 0E 98 2C

#### Exp Module DI Exception

01 02 10 01 CE 99 B9

01	Slave Address
02	Function (Read DI's)
00	I/O Address High (0-15 = Base, 16-31=EXP module 1)
01	Byte Count
0E	Digital Inputs (8-DI's) 1110
98	Checksum High
2C	Checksum Low

### 5.1.5.3 Analog Exception Format

#### Base Module AI exception

01 04 00 08 00 00 00 00 00 00 00 00 98 2C

#### Exp Module AI Exception

01 04 10 08 00 00 00 00 00 00 00 00 99 B9

01	Slave Address
04	Function (Read AI's)
00	I/O Address High (0-15 = Base, 16-31=EXP module 1)
08	Byte Count 08
00	Analog Input-1 High Byte
00	Analog Input-1 Low Byte
00	Analog Input-2 High Byte
00	Analog Input-2 Low Byte
00	Analog Input-3 High Byte
00	Analog Input-3 Low Byte
00	Analog Input-4 High Byte
00	Analog Input-4 Low Byte
98	Checksum High
2C	Checksum Low

To set the option of Exception Reporting:

1. Go to Zlinx Manager.
2. On the Input/Output Tab enable Exception Reporting option for the selected Input of the required module.




Figure 46 Window for setting Exception Reporting option

### 5.1.6 Calibration

It is possible to set a Calibration option in Zlinx Manager. Set Calibration option if you desire to better match a sensor, or a portion of a signal, to the I/O. Calibration feature can be applied for both Base and Expansion Modules.

There are two methods of Calibration:

- Single Point

Only one data point is used. The gain is 1 and the offset is the difference between the reference and acquired values.

- Two Point

The two data points are used to create a line. The gain is the slope of the line and the offset is the intercept.

**NOTE:** Power cycle does not reset Calibration settings.

To set Calibration for Analog Inputs:

1. Put a known value on the Analog Input.
2. Enter this value in the Reference text box.
3. Click the Read Current Value button.
4. The Acquired text box will be filled in with the acquired value.

If using the Two Point method, repeat these steps for the second calibration point.




Figure 47 Window for setting AI Calibration

To set Calibration for Analog Outputs:

1. Enter a value in the Reference text box.
2. Click the Set Current value button.
3. Supply power to the device.
4. Measure the output value and enter the measured value in the Acquired text box.
5. Values will be filled in automatically in the calibration field.

If using the Two Point method, repeat these steps for the second calibration point.




Figure 48 Window for setting AO Calibration

## 5.1.7 Failsafe

Failsafe mode can be enabled using Zlinx Manager. This feature applies to Base and Expansion Modules. This affects AO's and DO's only. The Failsafe feature allows outputs to go to a user defined level in the event that communication with the Modbus master (in Modbus mode) or peer (in Peer-to-Peer mode) is lost. The user selects the time frame of communication failure (see section 5.1.3) and values for all analog and digital output values. When communication failure happens outputs go to user-defined values. The default setting is disabled.




Figure 4049 Window for setting Failsafe command

## 5.1.8 Communication Failure Alarm

This feature provides an ability to configure DO-1 on the Base Module to be a communication failure alarm indicator. This feature applies only to Base Modules. While in this mode the Digital Output will only indicate communication failure and will not function as a regular Digital Output. DO-1 on Base Modules may be turned ON (low) in case of communication failure for a user-defined period of time (see section 0, 5.1.3).

**NOTE:** The system will not allow Failsafe and Communication Failure Alarm to be enabled at the same time. DO-1 will not function as a normal DO when configured to indicate Communication Failure.




Figure 41 Window for setting Communication Failure Alarm option

### 5.1.9 Invert Output

The user can invert logic of all Digital Outputs when such option is enabled. The feature applies to Base and Expansion Modules. With such settings if the signal coming to the affected Digital Output is ON (low), the Digital Output will show OFF (high).

**NOTE:** This feature applies to other options such as Failsafe or Communication Failure Alarm for the outputs.




Figure 42 Invert Output settings window

### 5.1.10 Zlinx I/O Monitor

From Zlinx Manager the user can choose the option Zlinx I/O Monitor. This option allows the monitoring of all Analog and Digital I/O values (in V, mA, on/off; degrees Celsius for RTD) real time.

To start the Monitor feature:

1. Start Zlinx Manager.
2. Choose Zlinx I/O Monitor from the list.
3. Zlinx I/O Monitor window will open.
4. Choose the COM port the system is connected to.
5. Click on the **Start Monitoring** button.




Figure 43 Zlinx I/O Monitor

**NOTE:** Monitor doesn't show the inverted values for the DO's if such option is enabled.

### 5.1.11 Saving the Configuration

When all configuration settings are complete, click the **Update** button to save them in the Zlinx Wireless I/O Base Module.

1. After pressing the **Update** button the Configuration Manager switches to the Information tab.
2. The Progress bar at the bottom of the windows shows the progress of the update.
3. The Status bar displays the following text:

*Sending radio parameters to the Base Module.*

4. When the updating process is complete, it is possible to switch to any other tab to see or edit any parameters.

**NOTE:** When configuration is complete and saved, power can be removed from the Base Module and the ZZ-PROG1 or ZZ-PROG1-USB Configuration Box should be disconnected and removed.

## 5.2 Updating Zlinx I/O Firmware

Occasionally, updated firmware becomes available for Zlinx Wireless I/O modules. When the Zlinx Manager software is installed on your computer the Zlinx Wireless I/O Firmware Updater software is also installed. This can be used to update the firmware in your Zlinx Wireless I/O modules. The following procedure describes the firmware updating process:

1. Disconnect power from the Base Module.
2. Disconnect all modules from external equipment. The easiest way to disconnect is to unplug all I/O terminal blocks.

3. With power disconnected from the Base Module connect Expansion Modules requiring updates to the Base Module. The male local bus connector on the first Expansion Module plugs into the female connector on the Base Module. The second Expansion Module plugs into the first, etc.
4. With power disconnected from the Base Module, plug the Configuration Box to the right side of the system.
5. Connect the PC serial port (COM 1 to 16) to the Configuration Box using a straight-through serial (9 pin) cable or USB cable if using the ZZ-PROG1-USB.
6. From the Windows **Start** menu, start the Zlinx Manager and choose Zlinx I/O Firmware Updater software.

The Zlinx I/O Firmware Updater Caution dialog box appears.




Figure 44 Firmware Updater Caution Dialog Box

7. Select the COM port from the Connection drop down list.
8. Click **Connect**.
9. Re-apply power to the Zlinx Wireless I/O Base Module. The Power LED should go on and stay on.
10. The Zlinx I/O Firmware Updater window opens and displays a list of the Base and Expansion Modules.
11. On the module list, select the Base or Expansion Module to be updated.
12. In the Firmware Image drop down box, select the image file (.hex).
13. Click the **Program** button to load the firmware into the module.
14. Repeat steps 11 to 13 for the other modules in the system.
15. When all updates are complete, click **Exit**.
16. Before reconnecting the I/O, and before disconnecting the Configuration Box, run the Zlinx Manager software and check to ensure all modules are configured properly.
17. When the configuration check is complete:
  - a. Exit the Zlinx Manager program.
  - b. Disconnect power from the Base Module.
  - c. Remove the Configuration Box.
  - d. Reconnect the I/O.

- e. Re-connect power to the Base Module.

**NOTE:** It is necessary to perform Power Cycle on all modules after Firmware Update.

## 5.3 Diagnostics and Testing

Most problems are related to incorrect configuration, or radio path problems. Before performing final installation of the Zlinx Wireless I/O modules, bench test the functionality first. If it does not work properly in this test, it will not work properly installed. If problems are found, check wiring and software configurations.

If the bench-test is successful, and problems are experienced after installation, check the radio path.

### 5.3.1 Testing Modbus Mode Operation

Using a Modbus radio modem, a PC and Modbus simulation software (e.g. Modscan) you can test the link and hardware, and investigate the operation of the Zlinx Wireless I/O. Modscan is a Windows application that simulates a Modbus Master node. You can read from and write to memory locations on the Zlinx Wireless I/O. Modscan is available as a fully functional time-limited demo from [www.win-tech.com](http://www.win-tech.com)

### 5.3.2 Testing Peer-to-Peer Mode Operation

To diagnose possible problems in Peer-to-Peer mode perform the following checks:

1. You must define one of the two Peer-to-Peer base devices as a MASTER and the other as a SLAVE.
2. You must have an equal number of Expansion Modules attached to the Master and Slave units.
3. You must define a "Polling" rate on the Master device. Typically a setting of "0" or "1" seconds works best.

**NOTE:** "0" causes the firmware to transfer data as fast as possible.

4. For Generation II devices, you must define a Slave "Communications Failure Timeout". Typically a setting of "20" seconds works best.
5. Both units must have the same Peer-to-Peer Address.
6. Both units must have the same Wireless setting for: "Channel", and "Network Identifier".

Test communications between the units by performing the following tests.

1. Confirm the **RF Data** LED's on the Master and Slave devices are flashing, indicating communications between the Master and Slave devices.
2. If the **RF Data** and **Bus** LED's are flashing in a "Rail-Road" manner, the system is NOT communicating.
3. On the Master system connect an LED to DO-1 of the Base Module. The LED should immediately come ON.
4. On the Slave system connect a wire from ground to DI-1 of the Base Module. The LED of the Master device should shut OFF.



## 6. Expected Latency

Before you lift a finger towards the perfect wireless installation, think about the impact of wireless communications on your application. Acceptable bit error rates are many orders of magnitude higher than wired communications. Most radios quietly handle error detection and retries for you - at the expense of throughput and variable latencies.

Software must be well designed and communication protocols must be tolerant of variable latencies. Not every protocol can tolerate simply replacing wires with radios. Protocols sensitive to inter-byte delays may require special attention or specific protocol support from the radio. Do your homework up front to confirm that your software won't choke, that the intended radio is friendly towards your protocol, and that your application software can handle it as well.

Assumptions:

- No RF retries.
- Units were less than 3 feet apart during the testing in a clean RF environment.

### 6.1 Modbus Mode

Modbus with 6 Expansion Modules					
Reading Inputs			Setting Outputs		
SR Base	MR Base	LR Base	SR Base	MR Base	LR Base
40mS	623mS	105mS	16mS	66mS	18mS

Modbus with no Expansion Modules					
Reading Inputs			Setting Outputs		
SR Base	MR Base	LR Base	SR Base	MR Base	LR Base
15mS	365mS	104mS	8mS	56.2mS	9mS

*NOTE: Add 45mS per analog Expansion Module and 25mS per digital Expansion Module. ZZ8D-Nx-LR radios have a 10% duty cycle max and were not included in the Latency testing.*

## 6.2 Peer-to-Peer Mode

Latency in Peer-to-Peer Mode		
Base Modules	Digital	Analog
ZZ24D-xx-SR	20mS	25mS
ZZxxD-xx-MR	827mS	643mS
ZZ9D-xx-LR-xx	55mS	52mS

*NOTE: Add 45mS per analog Expansion Module and 25mS per digital Expansion Module. ZZ8D-Nx-LR radios have a 10% duty cycle max and were not included in the Latency testing.*

## 7. Receive Sensitivity

The over-the-air data rate or RF data rate has a direct relationship to the receive sensitivity.

When comparing radios, it's critical to look at receive sensitivity and RF data rate. The lower the receive sensitivity the better the range.

Model	Freq	RF Baud	Sen db
ZP24D-250RM-SR ZZ24D-Nx-SR	2.4GHz	250K	-102dbm
ZP9D-115RM-LR ZZ9D-Nx-LR	900MHz	115.2K 9600	-100dbm @ 115.2K -110dbm @ 9600
ZP9D-115RM-LR-AU ZZ9D-Nx-LR-AU	900MHz	115.2K 9600	-100dbm @ 115.2K -110dbm @ 9600
ZP9D-96RM-MR ZZ9D-Nx-MR	900MHz	9.6K	-110dbm @ 9600
ZP24D-96RM-MR ZZ24D-Nx-MR	2.4GHz	9.6K	-105dbm @ 9600
ZP8D-24RM-LR ZZ8D-Nx-LR	868MHz	24K	-112dbm

## 8. Software Support

### 8.1 Support CD Information

Zlinx Wireless I/O software CD contains a folder “Manual”. Within this folder you can find the following supporting documentation:

- Zlinx Wireless I/O manual.
- Zlinx 485 manual.
- Zlinx Radio Modem (LR)
- Zlinx Radio Modem (SR).
- Zlinx Radio Modem (MR).
- Zlinx 485 Quick Start Guide.

### 8.2 Menu

The **Help** button in the Zlinx I/O application provides information on the component you are currently using.

To view the software revision number:

1. Open Zlinx Manager.
2. Go to **Help** menu and click on the **About** menu item.
3. The window will open with the revision number.

Zlinx Wireless I/O application allows you to enable a sidebar which provides information on options for Zlinx I/O.

To enable the sidebar:

1. Go to **Help** menu and choose **Sidebar** menu item.
2. On the right you will see the sidebar with the information on options.

### 8.3 Online Documentation

Zlinx Wireless I/O products include a set of manuals and Quick Start Guides in HTML and PDF format. You can find product details for a specific model number, visit technical library, request a free printed catalog by visiting the following website: <http://bb-elec.com/support.asp>

### 8.4 Getting Documents in Hardcopy

Zlinx Wireless I/O modules ship with the following documents in hardcopy:

- Modbus Mode Zlinx I/O Quick Start Guide.
- Peer-to-Peer Zlinx I/O Quick Start Guide.

Other books associated with this product suite can be found on our website: <http://bb-elec.com/support.asp>

---

## 8.5 B&B Electronics Information

Free Technical Support Contact Information  
Phone: 1-800-346-3119 (8-5 CST, M-F)  
Fax: (815) 433-5104 Attn: Support  
Email: [support@bb-elec.com](mailto:support@bb-elec.com)

## 9. Troubleshooting

This section is designed to help you answer some of the more common questions asked regarding installation and configuration of Zlinx Wireless I/O.

Problem	Causes and Resolutions
Power LED is not on	<ul style="list-style-type: none"> <li><input type="checkbox"/> Insure that power connections to the Base Module are properly connected and correct power voltage and current is applied.</li> </ul>
Bus LED's on Expansion Modules not blinking green	<ul style="list-style-type: none"> <li><input type="checkbox"/> Insure that all Expansion Modules are correctly assembled and bus connectors are correctly seated to insure proper connection.</li> </ul>
RSSI LED and RF Data LED intermittently blink:	<ul style="list-style-type: none"> <li><input type="checkbox"/> Firmware does not match The firmware for all Base Modules must match and the firmware for all Expansion Modules must match. The firmware revision number may be viewed on the information tab of the configuration software. See section 5.2 "Updating Zlinx I/O Firmware". If the firmware does not match, then update the firmware with the Zlinx I/O Firmware Updater software.</li> <li><input type="checkbox"/> No Peer-to-Peer communication link The communication link is not established. Verify that all parameters in the configuration tab in the programming software are correct.  Make sure that there are no obstacles in the path of the wireless transmission.</li> <li><input type="checkbox"/> Too many Expansion Modules installed Only 6 Expansion Modules may be connected to any Base Module.</li> <li><input type="checkbox"/> Expansion Modules in Peer-to-Peer mode do not match In Peer-to-Peer mode, the Master and Slave must have the same number of complimentary Expansion Modules.</li> <li><input type="checkbox"/> Expansion Module added/removed without cycling power on Base Module The Zlinx Wireless I/O configures the Base Module and Expansion Modules on a cycle of power. No damage occurs by adding/removing a module "hot" but the power does need to be cycled for the Base Module to update the expansion locations.</li> </ul>

## 9.1 Testing Digital and Analog I/O

There are simple tests that can be performed to confirm the functionality of the hardware and wiring configurations. The following diagrams can be used to aid in diagnosing problems with device connections.

To properly connect a Digital Output to the Digital Input of your data acquisition equipment, you need to know whether the output is “sinking” or “sourcing”. A “sinking” output acts simply as a switch to ground and may be referred to as a dry contact. A “sinking” output requires an additional power source for connected devices or an internal pull up resistor. A “sourcing” output supplies the voltage itself and requires a pull down resistor between the digital input or output and ground to provide the low voltage condition when the output is turned off.

To test devices you need to create a working system. For the purpose of the test create a system in Peer-to-Peer mode. Create two systems: System-1 consisting of a Base Module and an Expansion Module, System-2 consisting of a Base Module and an Expansion Module. Both Base Modules must be the same model. Analog and Digital Input signals connected to AI's and DI's on one system appear on the corresponding AO's and DO's on the other system and vice versa. Any Expansion Modules included in a Peer-to-Peer system must be chosen to be complimentary. For example, if Expansion Module 1 on System-1 is a ZZ-4AI (4 Analog Inputs), Expansion Module 1 on the other System-2 must be a ZZ-4AO (4 Analog Outputs).

### 9.1.1 Testing DI

A Digital Input is used to sense a high or low, such as a switch closure. To test the device, on System-1 connect one side of the switch to the DI on the Zlinx Wireless I/O device and the other side of the switch to ground on the Zlinx Wireless I/O device (see Figure 45). When the switch is closed the LED on the corresponding DO (assuming it is a sourcing DO) on System-2 should be OFF (low), when the switch is open the LED should be ON (high).




Figure 45 Digital Input wiring

### 9.1.2 Testing DO with Sourcing Driver

To test a “sourcing” output the following can be performed, remember that a “sourcing” output supplies the voltage itself. See “Appendix E: Zlinx Wireless I/O Models and Features” to find out which modules are sourcing. On System-1 on the corresponding Zlinx Wireless I/O device connect an LED between COM and DO, a pull down resistor between the Digital Output and LED may be required to provide the low voltage condition when the output is turned off (see Figure 46). Make sure to check the polarity of the LED while connecting it. On System-2 perform contact closure on the corresponding DI, confirm that the LED on System-1 is OFF with contact closed and ON with contact opened. For a power supply equal to 12VDC connected to the Base Module use  $R1 \approx 550 \Omega$ .




Figure 46 Digital Output (Sourcing driver) wiring

### 9.1.3 Testing DO with Sinking Driver

To test a “sinking” output the following can be performed, remember that a “sinking” output will need a power source. On the corresponding Zlinx Wireless I/O device of System-1 (see Figure 47) connect an LED between DO and additional power source as in section 9.1.2. Also connect a resistor  $\sim 550\Omega$  for a power supply equal to 12VDC connected to the Base Module. Perform contact closure on the DI side of System-2 and confirm that LED on System-1 is OFF with contact closed and ON with contact opened.






Figure 47 Digital Output (Sinking driver) wiring

### 9.1.4 Testing AI in “Voltage” Mode

Connect an AA battery (1.5 VDC) on the AI-1 on System-1 (see Figure 48) and a voltmeter on the corresponding AO-1 on System-2. Make sure the polarity is correct while connecting the battery. Measure the voltage on the Analog Output on System-2. It has to indicate 1.5 VDC.




Figure 48 Analog Input wiring

### 9.1.5 Testing AO in “Voltage” Mode

To test an Analog Output in “voltage” mode the following can be performed. Refer to “Appendix E: Zlinx Wireless I/O Models and Features” for the list of Analog Output modules. On the corresponding Zlinx Wireless I/O device on System-1 connect an AO to a voltmeter as shown in the figure below (Figure 49). Supply a voltage signal on the AI side of System-2. Confirm on System-1 with a voltmeter that the voltage on the corresponding output matches the voltage input.




Figure 49 Analog Output (Sourcing driver) wiring

### 9.1.6 Testing AI in “Current” Mode

To check an AI configured in “Current” mode use a ZZ-4AO-2 module (sourcing AO) as a source of current for the analog input module (see Figure 50). Both modules need to be in current mode. Set the system up as a Modbus system with two unique Modbus addresses. Set an output value for the ZZ-4AO-2 device and then read the input value on the corresponding analog input module that is being tested. It should match the output value that was set for the ZZ-4AO-2 module.




Figure 50 Providing the current signal for the Analog Input wiring with help of the ZZ-4AO-2

### 9.1.7 Testing RTD module

Connect two wires (I+ and I-) on System-1 to a resistor with known nominal values, for example 100Ω for Pt100, 1000Ω for Pt1000, and 10Ω for Cu 10. These values correspond to ~ 0 degree C. (see Figure 51). In the Zlinx I/O Configuration choose the following configuration setting: Peer-to-Peer mode, 2-wire mode, Pt100 connection (if using 100 Ω input). Connect a voltmeter to the corresponding AO on System-2. To verify the output voltage you will need to convert the ~ 0°C input to a voltage. To do this you can refer to Appendix F: RTD Module.




Figure 51 RTD (2-wire) connection diagram



## Appendix A: Default Configuration Settings

<b>Power Setting:</b>	SR Base Modules, 63mW, MR Base Modules, 50mW, LR Bae Modules, 1000mW, ZZ8D-xx-LR Base Modules, 316mW
<b>Wireless Channel Number:</b>	0x0C for SR Base Modules 0x00 for MR and ZZ9D-Nx-LR-xx Base Modules Single Channel for the ZZ8D-Nx-LR Base Modules
<b>Wireless Network ID:</b>	0x00 for SR Base Modules 0x10 for MR Base Modules 0x11 for ZZ9D-Nx-LR-xx Base Modules 0x00 for ZZ8D-Nx-LR Base Modules
<b>Repeater Mode:</b>	Not selected
<b>Communication Mode:</b>	Modbus
<b>Modbus Address:</b>	1
<b>Digital Inputs:</b>	Discrete
<b>Analog Inputs:</b>	0 to 10 VDC
<b>Analog Outputs:</b>	0 to 10 VDC

## Appendix B: Product Specifications

<b>Base Module Models:</b>	ZZ24D-NA-SR, ZZ24D-NB-SR, ZZ24D-NC-SR, ZZ24D-ND-SR ZZ24D-NA-MR, ZZ24D-NB-MR, ZZ24D-NC-MR, ZZ24D-ND-MR ZZ9D-NA-MR, ZZ9D-NB-MR, ZZ9D-NC-MR, ZZ9D-ND-MR ZZ9D-NA-LR, ZZ9D-NB-LR, ZZ9D-NC-LR, ZZ9D-ND-LR ZZ9D-NA-LR-AU, ZZ9D-NB-LR-AU, ZZ9D-NC-LR-AU, ZZ9D-ND-LR-AU; ZZ8D-NA-LR, ZZ8D-NB-LR, ZZ8D-NC-LR, ZZ8D-ND-LR
<b>Expansion Module Models:</b>	ZZ-4AI, ZZ-4AO, ZZ-2AI2AO, ZZ-8DI-DC, ZZ-8D0-T, ZZ-8D0-T1, ZZ-4DI4DO-DCT, ZZ-4DI4DO-DCT1, ZZ8DO-R, ZZ4RTD1, ZZ-4AO-2
<b>Manual:</b>	Electronic version of this manual, PDF available
<b>CD-ROM disc:</b>	Zlinx Manager PDF of Zlinx Wireless I/O User Manual PDF of Quick Start guide
<b>Operating Systems supported:</b>	Windows 2000/XP, Windows 7
<b>Dimensions:</b>	1.15 x 3.65 x 5 in (2.92 x 9.27x 12.7 cm)
<b>Expansion Feature:</b>	1 Base Module and up to 6 Expansion Modules
<b>Radio Properties</b>	
<b>Short Range (SR) Option:</b>	Up to 300 ft indoors / 1 mile outdoors (LOS)
<b>Medium Range (MR) Option:</b>	Up to 1500 ft indoors / 7 miles outdoors (LOS)
<b>ZZ9D-Nx-LR-xx Option</b>	Up to 1500 ft indoors / 7 miles outdoors (LOS)
<b>ZZ8D-Nx-LR Option:</b>	Up to 1800 ft indoors / 25 miles outdoors (LOS)
<b>Antennas:</b>	For 2.4 GHz models: 4.25 inch omni-directional rubber duck antenna. PN: ZZ24D-ANT1 For 900 and 868 MHz models: 6.5 inch omni-directional rubber duck antenna. PN: ZZ9D-ANT1
<b>LED Indicators</b>	
<b>Receive Signal Strength Indicator:</b>	Tri-color LED (Off = no signal, Red = weak, Yellow = OK, Green = Strong)
<b>RF Data Indicator:</b>	Green LED (blinks with TD or RD data traffic, Off = no data traffic)
<b>Bus Indicator:</b>	Green LED (blinks with TD or RD data traffic, Off = no data traffic)
<b>Power Indicator:</b>	Red LED
<b>I/O Connectors:</b>	Removable screw terminal blocks: 2 position: 3,81mm spacing; 3, 4 and 8 position: 3.5 mm spacing
<b>Digital Inputs</b>	
<b>Voltage Range:</b>	0 to 48 VDC
<b>Low Voltage (0):</b>	0.8 VDC maximum
<b>High Voltage (1):</b>	4.0 VDC minimum
<b>Pull up/down current:</b>	38uA

<b>Frequency Input:</b>	Two DI inputs per module software selectable as Counters, 0 to 5 kHz range (do NOT exceed more than 5kHz)
<b>Digital Outputs</b>	
<b>Voltage Range:</b>	10 to 40 VDC (for sourcing outputs), 0 to 48 VDC (for sinking outputs)
<b>Open Source:</b>	40mA per output
<b>Analog Inputs/Outputs</b>	
<b>Ranges:</b>	0 to 10 VDC or 0 to 20mA
<b>Resolution:</b>	12 bit
<b>Input Accuracy:</b>	0.2 % full scale reading typical, 0.5 % max
<b>Output Accuracy:</b>	0.27 % full scale reading typical, 0.63 % max
<b>AI Load Resistance:</b>	100 Mega ohms when configured for voltage input 250 ohms when configured for current input
<b>AO Max Output Current:</b>	1mA when configured for voltage output
<b>AO Max Source Load:</b>	450 ohms when configured for current output
<b>Input Protection:</b>	Over-voltage to 2x max input voltage
<b>Power Supply Voltage Requirements:</b>	10 VDC to 40 VDC, 24 VAC $\pm$ 10%
<b>Power Supply:</b>	Not included
<b>Base Module Power Connector:</b>	Removable screw terminal block, 2-position, 3.81 mm spacing
<b>Relay Outputs</b>	
<b>Number of Relays:</b>	8
<b>Type:</b>	C (normally open and normally closed)
<b>Output Connection:</b>	3.5mm removable terminal block (2 per output)
<b>Common Connection:</b>	3.5mm removable terminal block (1 per bank of 4 output)
<b>Ratings:</b>	250 VAC @ 8A, 30 VDC @ 5A (maximum per bank of 4 as grouped on the label)
<b>RTD Inputs</b>	
<b>Number of RTD:</b>	4
<b>Wire configuration:</b>	2, 3, and 4 wire
<b>Type:</b>	Pt100*, Pt1000*, Cu 10** *Optimized for temperature coefficient of 385 **Optimized for temperature coefficient of 427
<b>Input Connection:</b>	3.5mm removable terminal block (4 per output)
<b>Temperature Range:</b>	Pt100 = -200 to 650° C Pt1000 = -200 to 100° C Cu 10 = -100 to 260° C ( <b>Note:</b> The RTD data value is scaled to 0-65535 & must be read as an unsigned integer when read by a Modbus master (PLC / SCADA / etc.)
<b>Resolution:</b>	0.1° C across -40 to 85° C
<b>Accuracy @ 25°C:</b>	$\pm$ 0.5°C typical

<b>Accuracy -40 to 85°C:</b>	±2.0°C maximum	
<b>Power Consumption:</b>	SR = 10W Max MR = 9.5W ZZ9D-Nx-LR-xx = 13.1W ZZ8D-Nx-LR = 12W ZZ-4AI = 1W ZZ-4AO = 1.1W ZZ-2AI2AO = 1.2W ZZ-8DI-DC = 0.4W ZZ-8DO-T = 15.8W ZZ-8DO-T1 = 1.1W ZZ-4DI4DO-DCT = 8.1W ZZ-4DI4DO-DCT1 = 1.0W ZZ-8DO-R = 3.2W ZZ-4RTD1 = 0.4W ZZ-4AO-2 = 6.0W	
<b>Operating Temperature:</b>	-40 to 80°C (-40 to 176 °F) -40 to 55°C (-40 to 131 ° F) for ZZ-8DO-R only	
<b>Storage Temperature:</b>	-40 to 85 °C (-40 to 185 °F)	
<b>Humidity:</b>	0 to 90% R.H. non-condensing	
<b>Enclosure Rating:</b>	IP30	
<b>Mounting:</b>	DIN rail mount, 35 mm	
<b>Certifications:</b>	FCC: Part 15 Class A CISPR (EN55022) Class A EN61000-6-1 Generic Standards for Residential, Commercial & Light Industrial EN61000-4-2 ESD EN61000-4-3 RFI EN61000-4-4 EFT EN61000-4-5 Surge EN61000-4-6 CI EN61000-4-8 Power Frequency Magnetic EN61000-4-11 Voltage Dips & Interruptions. UL & cUL File Numbers E245458 (Class 1, Div 2) & E222870 (UL508) <b>Note:</b> ZZ-8DO-R is not UL508 listed but is Class 1, Div 2 listed <b>Note:</b> ZZxD-Nx-MR models are UL508 listed but not Class 1, Div 2 listed	
<b>Accessories and Replacement Parts:</b>	ZZ-DIN1	DIN clip and spring for all ZZ products, 4 spare screws for enclosure.
	ZZ-TB1	Removable terminal block for all ZZ modules. Includes two 2 Pos, two 4 Pos, two 8 Pos terminal blocks and one shroud cover for box.
	ZZ24D-ANT1	2.4 GHz band antenna.
	ZZ9D-ANT1	900/868 MHz band antenna.
	ZZ-PROG1	Configuration Box, serial cable, and hardcopy of Quick Start Guides.
	ZZ-PROGKIT	Configuration Box, serial cable, CD with Zlinx Manager software and hardcopy of Quick Start Guides.
	ZZ-PROGKIT-USB	Configuration Box, USB cable, CD with Zlinx Manager software and hardcopy of Quick Start Guides.
	195M-SLSW-24	Antenna cable.

## Appendix C: Dimensional Diagrams




Figure 52 Dimensional Diagram of a Zlinx Wireless I/O Base Module



## Appendix D: Modbus I/O Assignments

### 00001-00112 Discrete Digital Outputs

Modbus function codes supported are:

- Function 1: Read DO Status
- Function 2: Read DI's
- Function 3: Read AO Status
- Function 4: Read AI's
- Function 5: Write to Single DO (firmware v2.0 or higher)
- Function 6: Write to Single AO
- Function 15: Write to Multi DO's

Modbus Address	Description	#Bytes	Count	V Range
00001	Base Digital Output-1	-	0-1	Refer to Appendix B
00002	Base Digital Output-2	-	0-1	Refer to Appendix B
00003	Base Digital Output-3	-	0-1	Refer to Appendix B
00004	Base Digital Output-4	-	0-1	Refer to Appendix B
00005	Base Digital Output-5	-	0-1	Refer to Appendix B
00006	Base Digital Output-6	-	0-1	Refer to Appendix B
00007	Base Digital Output-7	-	0-1	Refer to Appendix B
00008	Base Digital Output-8	-	0-1	Refer to Appendix B
00009	Base Digital Output-9	-	0-1	Refer to Appendix B
00010	Base Digital Output-10	-	0-1	Refer to Appendix B
00011	Base Digital Output-11	-	0-1	Refer to Appendix B
00012	Base Digital Output-12	-	0-1	Refer to Appendix B
00013	Base Digital Output-13	-	0-1	Refer to Appendix B
00014	Base Digital Output-14	-	0-1	Refer to Appendix B
00015	Base Digital Output-15	-	0-1	Refer to Appendix B
00016	Base Digital Output-16	-	0-1	Refer to Appendix B
00017	EXP-1 Digital Output-1	-	0-1	Refer to Appendix B
00018	EXP-1 Digital Output-2	-	0-1	Refer to Appendix B
00019	EXP-1 Digital Output-3	-	0-1	Refer to Appendix B
00020	EXP-1 Digital Output-4	-	0-1	Refer to Appendix B
00021	EXP-1 Digital Output-5	-	0-1	Refer to Appendix B
00022	EXP-1 Digital Output-6	-	0-1	Refer to Appendix B
00023	EXP-1 Digital Output-7	-	0-1	Refer to Appendix B
00024	EXP-1 Digital Output-8	-	0-1	Refer to Appendix B
00025	EXP-1 Digital Output-9	-	0-1	Refer to Appendix B
00026	EXP-1 Digital Output-10	-	0-1	Refer to Appendix B
00027	EXP-1 Digital Output-11	-	0-1	Refer to Appendix B
00028	EXP-1 Digital Output-12	-	0-1	Refer to Appendix B
00029	EXP-1 Digital Output-13	-	0-1	Refer to Appendix B
00030	EXP-1 Digital Output-14	-	0-1	Refer to Appendix B
00031	EXP-1 Digital Output-15	-	0-1	Refer to Appendix B
00032	EXP-1 Digital Output-16	-	0-1	Refer to Appendix B
00033	EXP-2 Digital Output-1	-	0-1	Refer to Appendix B
00034	EXP-2 Digital Output-2	-	0-1	Refer to Appendix B
00035	EXP-2 Digital Output-3	-	0-1	Refer to Appendix B
00036	EXP-2 Digital Output-4	-	0-1	Refer to Appendix B
00037	EXP-2 Digital Output-5	-	0-1	Refer to Appendix B
00038	EXP-2 Digital Output-6	-	0-1	Refer to Appendix B
00039	EXP-2 Digital Output-7	-	0-1	Refer to Appendix B
00040	EXP-2 Digital Output-8	-	0-1	Refer to Appendix B
00041	EXP-2 Digital Output-9	-	0-1	Refer to Appendix B
00042	EXP-2 Digital Output-10	-	0-1	Refer to Appendix B
00043	EXP-2 Digital Output-11	-	0-1	Refer to Appendix B
00044	EXP-2 Digital Output-12	-	0-1	Refer to Appendix B
00045	EXP-2 Digital Output-13	-	0-1	Refer to Appendix B
00046	EXP-2 Digital Output-14	-	0-1	Refer to Appendix B
00047	EXP-2 Digital Output-15	-	0-1	Refer to Appendix B
00048	EXP-2 Digital Output-16	-	0-1	Refer to Appendix B
00049	EXP-3 Digital Output-1	-	0-1	Refer to Appendix B
00050	EXP-3 Digital Output-2	-	0-1	Refer to Appendix B
00051	EXP-3 Digital Output-3	-	0-1	Refer to Appendix B
00052	EXP-3 Digital Output-4	-	0-1	Refer to Appendix B
00053	EXP-3 Digital Output-5	-	0-1	Refer to Appendix B
00054	EXP-3 Digital Output-6	-	0-1	Refer to Appendix B
00055	EXP-3 Digital Output-7	-	0-1	Refer to Appendix B
00056	EXP-3 Digital Output-8	-	0-1	Refer to Appendix B
00057	EXP-3 Digital Output-9	-	0-1	Refer to Appendix B
00058	EXP-3 Digital Output-10	-	0-1	Refer to Appendix B
00059	EXP-3 Digital Output-11	-	0-1	Refer to Appendix B
00060	EXP-3 Digital Output-12	-	0-1	Refer to Appendix B
00061	EXP-3 Digital Output-13	-	0-1	Refer to Appendix B
00062	EXP-3 Digital Output-14	-	0-1	Refer to Appendix B
00063	EXP-3 Digital Output-15	-	0-1	Refer to Appendix B
00064	EXP-3 Digital Output-16	-	0-1	Refer to Appendix B

Modbus Address	Description	#Bytes	Count	V Range
00065	EXP-4 Digital Output-1	-	0-1	Refer to Appendix B
00066	EXP-4 Digital Output-2	-	0-1	Refer to Appendix B
00067	EXP-4 Digital Output-3	-	0-1	Refer to Appendix B
00068	EXP-4 Digital Output-4	-	0-1	Refer to Appendix B
00069	EXP-4 Digital Output-5	-	0-1	Refer to Appendix B
00070	EXP-4 Digital Output-6	-	0-1	Refer to Appendix B
00071	EXP-4 Digital Output-7	-	0-1	Refer to Appendix B
00072	EXP-4 Digital Output-8	-	0-1	Refer to Appendix B
00073	EXP-4 Digital Output-9	-	0-1	Refer to Appendix B
00074	EXP-4 Digital Output-10	-	0-1	Refer to Appendix B
00075	EXP-4 Digital Output-11	-	0-1	Refer to Appendix B
00076	EXP-4 Digital Output-12	-	0-1	Refer to Appendix B
00077	EXP-4 Digital Output-13	-	0-1	Refer to Appendix B
00078	EXP-4 Digital Output-14	-	0-1	Refer to Appendix B
00079	EXP-4 Digital Output-15	-	0-1	Refer to Appendix B
00080	EXP-4 Digital Output-16	-	0-1	Refer to Appendix B
00081	EXP-5 Digital Output-1	-	0-1	Refer to Appendix B
00082	EXP-5 Digital Output-2	-	0-1	Refer to Appendix B
00083	EXP-5 Digital Output-3	-	0-1	Refer to Appendix B
00084	EXP-5 Digital Output-4	-	0-1	Refer to Appendix B
00085	EXP-5 Digital Output-5	-	0-1	Refer to Appendix B
00086	EXP-5 Digital Output-6	-	0-1	Refer to Appendix B
00087	EXP-5 Digital Output-7	-	0-1	Refer to Appendix B
00088	EXP-5 Digital Output-8	-	0-1	Refer to Appendix B
00089	EXP-5 Digital Output-9	-	0-1	Refer to Appendix B
00090	EXP-5 Digital Output-10	-	0-1	Refer to Appendix B
00091	EXP-5 Digital Output-11	-	0-1	Refer to Appendix B
00092	EXP-5 Digital Output-12	-	0-1	Refer to Appendix B
00093	EXP-5 Digital Output-13	-	0-1	Refer to Appendix B
00094	EXP-5 Digital Output-14	-	0-1	Refer to Appendix B
00095	EXP-5 Digital Output-15	-	0-1	Refer to Appendix B
00096	EXP-5 Digital Output-16	1	0-1	Refer to Appendix B
00097	EXP-6 Digital Output-1	-	0-1	Refer to Appendix B
00098	EXP-6 Digital Output-2	-	0-1	Refer to Appendix B
00099	EXP-6 Digital Output-3	-	0-1	Refer to Appendix B
00100	EXP-6 Digital Output-4	-	0-1	Refer to Appendix B
00101	EXP-6 Digital Output-5	-	0-1	Refer to Appendix B
00102	EXP-6 Digital Output-6	-	0-1	Refer to Appendix B
00103	EXP-6 Digital Output-7	-	0-1	Refer to Appendix B
00104	EXP-6 Digital Output-8	-	0-1	Refer to Appendix B
00105	EXP-6 Digital Output-9	-	0-1	Refer to Appendix B
00106	EXP-6 Digital Output-10	-	0-1	Refer to Appendix B
00107	EXP-6 Digital Output-11	-	0-1	Refer to Appendix B
00108	EXP-6 Digital Output-12	-	0-1	Refer to Appendix B
00109	EXP-6 Digital Output-13	-	0-1	Refer to Appendix B
00110	EXP-6 Digital Output-14	-	0-1	Refer to Appendix B
00111	EXP-6 Digital Output-15	-	0-1	Refer to Appendix B
00112	EXP-6 Digital Output-16	-	0-1	Refer to Appendix B

10001-10112 Discrete Digital Inputs

Modbus Address	Description	#Bytes	Count	V Range
10001	Base Digital Input-1	-	0-1	Refer to Appendix B
10002	Base Digital Input-2	-	0-1	Refer to Appendix B
10003	Base Digital Input-3	-	0-1	Refer to Appendix B
10004	Base Digital Input-4	-	0-1	Refer to Appendix B
10005	Base Digital Input-5	-	0-1	Refer to Appendix B
10006	Base Digital Input-6	-	0-1	Refer to Appendix B
10007	Base Digital Input-7	-	0-1	Refer to Appendix B
10008	Base Digital Input-8	-	0-1	Refer to Appendix B
10009	Base Digital Input-9	-	0-1	Refer to Appendix B
10010	Base Digital Input-10	-	0-1	Refer to Appendix B
10011	Base Digital Input-11	-	0-1	Refer to Appendix B
10012	Base Digital Input-12	-	0-1	Refer to Appendix B
10013	Base Digital Input-13	-	0-1	Refer to Appendix B
10014	Base Digital Input-14	-	0-1	Refer to Appendix B
10015	Base Digital Input-15	-	0-1	Refer to Appendix B
10016	Base Digital Input-16	-	0-1	Refer to Appendix B
10017	EXP-1 Digital Input-1	-	0-1	Refer to Appendix B
10018	EXP-1 Digital Input-2	-	0-1	Refer to Appendix B
10019	EXP-1 Digital Input-3	-	0-1	Refer to Appendix B
10020	EXP-1 Digital Input-4	-	0-1	Refer to Appendix B
10021	EXP-1 Digital Input-5	-	0-1	Refer to Appendix B
10022	EXP-1 Digital Input-6	-	0-1	Refer to Appendix B
10023	EXP-1 Digital Input-7	-	0-1	Refer to Appendix B
10024	EXP-1 Digital Input-8	-	0-1	Refer to Appendix B
10025	EXP-1 Digital Input-9	-	0-1	Refer to Appendix B
10026	EXP-1 Digital Input-10	-	0-1	Refer to Appendix B
10027	EXP-1 Digital Input-11	-	0-1	Refer to Appendix B
10028	EXP-1 Digital Input-12	-	0-1	Refer to Appendix B

Modbus Address	Description	#Bytes	Count	V Range
10029	EXP-1 Digital Input-13	-	0-1	Refer to Appendix B
10030	EXP-1 Digital Input-14	-	0-1	Refer to Appendix B
10031	EXP-1 Digital Input-15	-	0-1	Refer to Appendix B
10032	EXP-1 Digital Input-16	-	0-1	Refer to Appendix B
10033	EXP-2 Digital Input-1	-	0-1	Refer to Appendix B
10034	EXP-2 Digital Input-2	-	0-1	Refer to Appendix B
10035	EXP-2 Digital Input-3	-	0-1	Refer to Appendix B
10036	EXP-2 Digital Input-4	-	0-1	Refer to Appendix B
10037	EXP-2 Digital Input-5	-	0-1	Refer to Appendix B
10038	EXP-2 Digital Input-6	-	0-1	Refer to Appendix B
10039	EXP-2 Digital Input-7	-	0-1	Refer to Appendix B
10040	EXP-2 Digital Input-8	-	0-1	Refer to Appendix B
10041	EXP-2 Digital Input-9	-	0-1	Refer to Appendix B
10042	EXP-2 Digital Input-10	-	0-1	Refer to Appendix B
10043	EXP-2 Digital Input-11	-	0-1	Refer to Appendix B
10044	EXP-2 Digital Input-12	-	0-1	Refer to Appendix B
10045	EXP-2 Digital Input-13	-	0-1	Refer to Appendix B
10046	EXP-2 Digital Input-14	-	0-1	Refer to Appendix B
10047	EXP-2 Digital Input-15	-	0-1	Refer to Appendix B
10048	EXP-2 Digital Input-16	-	0-1	Refer to Appendix B
10049	EXP-3 Digital Input-1	-	0-1	Refer to Appendix B
10050	EXP-3 Digital Input-2	-	0-1	Refer to Appendix B
11051	EXP-3 Digital Input-3	-	0-1	Refer to Appendix B
10052	EXP-3 Digital Input-4	-	0-1	Refer to Appendix B
10053	EXP-3 Digital Input-5	-	0-1	Refer to Appendix B
10054	EXP-3 Digital Input-6	-	0-1	Refer to Appendix B
10055	EXP-3 Digital Input-7	-	0-1	Refer to Appendix B
10056	EXP-3 Digital Input-8	-	0-1	Refer to Appendix B
10057	EXP-3 Digital Input-9	-	0-1	Refer to Appendix B
10058	EXP-3 Digital Input-10	-	0-1	Refer to Appendix B
10059	EXP-3 Digital Input-11	-	0-1	Refer to Appendix B
10060	EXP-3 Digital Input-12	-	0-1	Refer to Appendix B
10061	EXP-3 Digital Input-13	-	0-1	Refer to Appendix B
10062	EXP-3 Digital Input-14	-	0-1	Refer to Appendix B
10063	EXP-3 Digital Input-15	-	0-1	Refer to Appendix B
10064	EXP-3 Digital Input-16	-	0-1	Refer to Appendix B
10065	EXP-4 Digital Input-1	-	0-1	Refer to Appendix B
10066	EXP-4 Digital Input-2	-	0-1	Refer to Appendix B
10067	EXP-4 Digital Input-3	-	0-1	Refer to Appendix B
10068	EXP-4 Digital Input-4	-	0-1	Refer to Appendix B
10069	EXP-4 Digital Input-5	-	0-1	Refer to Appendix B
10070	EXP-4 Digital Input-6	-	0-1	Refer to Appendix B
10071	EXP-4 Digital Input-7	-	0-1	Refer to Appendix B
10072	EXP-4 Digital Input-8	-	0-1	Refer to Appendix B
10073	EXP-4 Digital Input-9	-	0-1	Refer to Appendix B
10074	EXP-4 Digital Input-10	-	0-1	Refer to Appendix B
10075	EXP-4 Digital Input-11	-	0-1	Refer to Appendix B
10076	EXP-4 Digital Input-12	-	0-1	Refer to Appendix B
10077	EXP-4 Digital Input-13	-	0-1	Refer to Appendix B
10078	EXP-4 Digital Input-14	-	0-1	Refer to Appendix B
10079	EXP-4 Digital Input-15	-	0-1	Refer to Appendix B
10080	EXP-4 Digital Input-16	-	0-1	Refer to Appendix B
10081	EXP-5 Digital Input-1	-	0-1	Refer to Appendix B
10082	EXP-5 Digital Input-2	-	0-1	Refer to Appendix B
10083	EXP-5 Digital Input-3	-	0-1	Refer to Appendix B
10084	EXP-5 Digital Input-4	-	0-1	Refer to Appendix B
10085	EXP-5 Digital Input-5	-	0-1	Refer to Appendix B
10086	EXP-5 Digital Input-6	-	0-1	Refer to Appendix B
10087	EXP-5 Digital Input-7	-	0-1	Refer to Appendix B
10088	EXP-5 Digital Input-8	-	0-1	Refer to Appendix B
10089	EXP-5 Digital Input-9	-	0-1	Refer to Appendix B
10090	EXP-5 Digital Input-10	-	0-1	Refer to Appendix B
10091	EXP-5 Digital Input-11	-	0-1	Refer to Appendix B
10092	EXP-5 Digital Input-12	-	0-1	Refer to Appendix B
10093	EXP-5 Digital Input-13	-	0-1	Refer to Appendix B
10094	EXP-5 Digital Input-14	-	0-1	Refer to Appendix B
10095	EXP-5 Digital Input-15	-	0-1	Refer to Appendix B
10096	EXP-5 Digital Input-16	-	0-1	Refer to Appendix B
10097	EXP-6 Digital Input-1	-	0-1	Refer to Appendix B
10098	EXP-6 Digital Input-2	-	0-1	Refer to Appendix B
10099	EXP-6 Digital Input-3	-	0-1	Refer to Appendix B
10100	EXP-6 Digital Input-4	-	0-1	Refer to Appendix B
10101	EXP-6 Digital Input-5	-	0-1	Refer to Appendix B
10102	EXP-6 Digital Input-6	-	0-1	Refer to Appendix B
10103	EXP-6 Digital Input-7	-	0-1	Refer to Appendix B
10104	EXP-6 Digital Input-8	-	0-1	Refer to Appendix B
10105	EXP-6 Digital Input-9	-	0-1	Refer to Appendix B
10106	EXP-6 Digital Input-10	-	0-1	Refer to Appendix B
10107	EXP-6 Digital Input-11	-	0-1	Refer to Appendix B

Modbus Address	Description	#Bytes	Count	V Range
10108	EXP-6 Digital Input-12	-	0-1	Refer to Appendix B
10109	EXP-6 Digital Input-13	-	0-1	Refer to Appendix B
10110	EXP-6 Digital Input-14	-	0-1	Refer to Appendix B
10111	EXP-6 Digital Input-15	-	0-1	Refer to Appendix B
10112	EXP-6 Digital Input-16	-	0-1	Refer to Appendix B

30001-30112 Analog Inputs

Modbus Address	Description	#Bytes	A/D Count	(V)/(I)Range
30001	Base Analog Input-1	2	0-4095	0-10vdc/0-20ma
30002	Base Analog Input-2	2	0-4095	0-10vdc/0-20ma
30003	Base Analog Input-3	2	0-4095	0-10vdc/0-20ma
30004	Base Analog Input-4	2	0-4095	0-10vdc/0-20ma
30005	System Input Power	2	0-1023	0-40vdc
30006	Base Analog Input-6	2	0-4095	0-10vdc/0-20ma
30007	Base Analog Input-7	2	0-4095	0-10vdc/0-20ma
30008	Base Analog Input-8	2	0-4095	0-10vdc/0-20ma
30009	Base Reserved	-	-	-
30010	Base Reserved	-	-	-
30011	Base Reserved	-	-	-
30012	Base Reserved	-	-	-
30013	Base Reserved	-	-	-
30014	Base Reserved	-	-	-
30015	Base Reserved	-	-	-
30016	Base Reserved	-	-	-
30017	EXP-1 Analog Input-1	2	0-4095/0-65535	0-10vdc/0-20ma/RTD*
30018	EXP-1 Analog Input-2	2	0-4095/0-65535	0-10vdc/0-20ma/RTD*
30019	EXP-1 Analog Input-3	2	0-4095/0-65535	0-10vdc/0-20ma/RTD*
30020	EXP-1 Analog Input-4	2	0-4095/0-65535	0-10vdc/0-20ma/RTD*
30021	EXP-1 Analog Input-5	2	0-4095	0-10vdc/0-20ma
30022	EXP-1 Analog Input-6	2	0-4095	0-10vdc/0-20ma
30023	EXP-1 Analog Input-7	2	0-4095	0-10vdc/0-20ma
30024	EXP-1 Analog Input-8	2	0-4095	0-10vdc/0-20ma
30025	EXP-1 Reserved	-	-	-
30026	EXP-1 Reserved	-	-	-
30027	EXP-1 Reserved	-	-	-
30028	EXP-1 Reserved	-	-	-
30029	EXP-1 Reserved	-	-	-
30030	EXP-1 Reserved	-	-	-
30031	EXP-1 Reserved	-	-	-
30032	EXP-1 Reserved	-	-	-
30033	EXP-2 Analog Input-1	2	0-4095	0-10vdc/0-20ma
30034	EXP-2 Analog Input-2	2	0-4095	0-10vdc/0-20ma
30035	EXP-2 Analog Input-3	2	0-4095	0-10vdc/0-20ma
30036	EXP-2 Analog Input-4	2	0-4095	0-10vdc/0-20ma
30037	EXP-2 Analog Input-5	2	0-4095	0-10vdc/0-20ma
30038	EXP-2 Analog Input-6	2	0-4095	0-10vdc/0-20ma
30039	EXP-2 Analog Input-7	2	0-4095	0-10vdc/0-20ma
30040	EXP-2 Analog Input-8	2	0-4095	0-10vdc/0-20ma
30041	EXP-2 Reserved	-	-	-
30042	EXP-2 Reserved	-	-	-
30043	EXP-2 Reserved	-	-	-
30044	EXP-2 Reserved	-	-	-
30045	EXP-2 Reserved	-	-	-
30046	EXP-2 Reserved	-	-	-
30047	EXP-2Reserved	-	-	-
30048	EXP-2 Reserved	-	-	-
30049	EXP-3 Analog Input-1	2	0-4095	0-10vdc/0-20ma
30050	EXP-3 Analog Input-2	2	0-4095	0-10vdc/0-20ma
30051	EXP-3 Analog Input-3	2	0-4095	0-10vdc/0-20ma
30052	EXP-3 Analog Input-4	2	0-4095	0-10vdc/0-20ma
30053	EXP-3 Analog Input-5	2	0-4095	0-10vdc/0-20ma
30054	EXP-3 Analog Input-6	2	0-4095	0-10vdc/0-20ma
30055	EXP-3 Analog Input-7	2	0-4095	0-10vdc/0-20ma
30056	EXP-3 Analog Input-8	2	0-4095	0-10vdc/0-20ma
30057	EXP-3 Reserved	-	-	-
30058	EXP-3 Reserved	-	-	-
30059	EXP-3 Reserved	-	-	-
30060	EXP-3 Reserved	-	-	-
30061	EXP-3 Reserved	-	-	-
30062	EXP-3 Reserved	-	-	-
30063	EXP-3Reserved	-	-	-
30064	EXP-3 Reserved	-	-	-
30065	EXP-4 Analog Input-1	2	0-4095	0-10vdc/0-20ma
30066	EXP-4 Analog Input-2	2	0-4095	0-10vdc/0-20ma
30067	EXP-4 Analog Input-3	2	0-4095	0-10vdc/0-20ma
30068	EXP-4 Analog Input-4	2	0-4095	0-10vdc/0-20ma
30069	EXP-4 Analog Input-5	2	0-4095	0-10vdc/0-20ma

Modbus Address	Description	#Bytes	A/D Count	(V)/(I)Range
30070	EXP-4 Analog Input-6	2	0-4095	0-10vdc/0-20ma
30071	EXP-4 Analog Input-7	2	0-4095	0-10vdc/0-20ma
30072	EXP-4 Analog Input-8	2	0-4095	0-10vdc/0-20ma
30073	EXP-4 Reserved	-	-	-
30074	EXP-4 Reserved	-	-	-
30075	EXP-4 Reserved	-	-	-
30076	EXP-4 Reserved	-	-	-
30077	EXP-4 Reserved	-	-	-
30078	EXP-4 Reserved	-	-	-
30079	EXP-4Reserved	-	-	-
30080	EXP-4 Reserved	-	-	-
30081	EXP-5 Analog Input-1	2	0-4095	0-10vdc/0-20ma
30082	EXP-5 Analog Input-2	2	0-4095	0-10vdc/0-20ma
30083	EXP-5 Analog Input-3	2	0-4095	0-10vdc/0-20ma
30084	EXP-5 Analog Input-4	2	0-4095	0-10vdc/0-20ma
30085	EXP-5 Analog Input-5	2	0-4095	0-10vdc/0-20ma
30086	EXP-5 Analog Input-6	2	0-4095	0-10vdc/0-20ma
30087	EXP-5 Analog Input-7	2	0-4095	0-10vdc/0-20ma
30088	EXP-5 Analog Input-8	2	0-4095	0-10vdc/0-20ma
30089	EXP-5 Reserved	-	-	-
30090	EXP-5 Reserved	-	-	-
30091	EXP-5 Reserved	-	-	-
30092	EXP-5 Reserved	-	-	-
30093	EXP-5 Reserved	-	-	-
30094	EXP-5 Reserved	-	-	-
30095	EXP-5Reserved	-	-	-
30096	EXP-5 Reserved	-	-	-
30097	EXP-6 Analog Input-1	2	0-4095	0-10vdc/0-20ma
30098	EXP-6 Analog Input-2	2	0-4095	0-10vdc/0-20ma
30099	EXP-6 Analog Input-3	2	0-4095	0-10vdc/0-20ma
30100	EXP-6 Analog Input-4	2	0-4095	0-10vdc/0-20ma
30101	EXP-6 Analog Input-5	2	0-4095	0-10vdc/0-20ma
30102	EXP-6 Analog Input-6	2	0-4095	0-10vdc/0-20ma
30103	EXP-6 Analog Input-7	2	0-4095	0-10vdc/0-20ma
30104	EXP-6 Analog Input-8	2	0-4095	0-10vdc/0-20ma
30105	EXP-6 Reserved	-	-	-
30106	EXP-6 Reserved	-	-	-
30107	EXP-6 Reserved	-	-	-
30108	EXP-6 Reserved	-	-	-
30109	EXP-6 Reserved	-	-	-
30110	EXP-6 Reserved	-	-	-
30111	EXP-6Reserved	-	-	-
30112	EXP-6 Reserved	-	-	-

\* - Note: The RTD data is scaled to 0-65535 & must be read as an unsigned integer when read by a Modbus master (PLC / SCADA / etc).

#### 40001-40112 Analog Outputs/Special Registers

Modbus Address	Description	#Bytes	D/A Count	(V)/(I)Range
40001	Base Analog Output-1	2	0-4095	0-10vdc/0-20ma
40002	Base Analog Output-2	2	0-4095	0-10vdc/0-20ma
40003	Base Analog Output-3	2	0-4095	0-10vdc/0-20ma
40004	Base Analog Output-4	2	0-4095	0-10vdc/0-20ma
40005	Base Analog Output-5	2	0-4095	0-10vdc/0-20ma
40006	Base Analog Output-6	2	0-4095	0-10vdc/0-20ma
40007	Base Analog Output-7	2	0-4095	0-10vdc/0-20ma
40008	Base Analog Output-8	2	0-4095	0-10vdc/0-20ma
40009	Base Freq Input – 1	2	0-5000	0-5000Hz
40010	Base Freq Input – 2	2	0-5000	0-5000Hz
40011	Accumulator Input 1 least significant count	2	0-9999	-
40012	Accumulator Input 1 most significant count	2	10000-99,999,999	-
40013	Accumulator Input 2 least significant count	2	0-9999	-
40014	Accumulator Input 2 most significant count	2	10000-99,999,999	-
40015	Time to Saves Totals (Seconds), counts down the number of seconds until the Accumulators are saved internally	2	300-0	-
40016	Base Reserved	-	-	-
40017	EXP-1 Analog Output-1	2	0-4095	0-10vdc/0-20ma
40018	EXP-1 Analog Output-2	2	0-4095	0-10vdc/0-20ma
40019	EXP-1 Analog Output-3	2	0-4095	0-10vdc/0-20ma
40020	EXP-1 Analog Output-4	2	0-4095	0-10vdc/0-20ma
40021	EXP-1 Analog Output-5	2	0-4095	0-10vdc/0-20ma
40022	EXP-1 Analog Output-6	2	0-4095	0-10vdc/0-20ma
40023	EXP-1 Analog Output-7	2	0-4095	0-10vdc/0-20ma
40024	EXP-1 Analog Output-8	2	0-4095	0-10vdc/0-20ma

Appendix D: Modbus I/O Assignments

Modbus Address	Description	#Bytes	D/A Count	(V)/(I)Range
40025	EXP-1 Freq Input – 1	2	0-5000	0-5000Hz
40026	EXP-1 Freq Input – 2	2	0-5000	0-5000Hz
40027	EXP-1 Reserved	-	-	-
40028	EXP-1 Reserved	-	-	-
40029	EXP-1 Address	2	0-1023	-
40030	EXP-1 Reserved	-	-	-
40031	EXP-1 Reserved	-	-	-
40032	EXP-1 Reserved	-	-	-
40033	EXP-2 Analog Output-1	2	0-4095	0-10vdc/0-20ma
40034	EXP-2 Analog Output-2	2	0-4095	0-10vdc/0-20ma
40035	EXP-2 Analog Output-3	2	0-4095	0-10vdc/0-20ma
40036	EXP-2 Analog Output-4	2	0-4095	0-10vdc/0-20ma
40037	EXP-2 Analog Output-5	2	0-4095	0-10vdc/0-20ma
40038	EXP-2 Analog Output-6	2	0-4095	0-10vdc/0-20ma
40039	EXP-2 Analog Output-7	2	0-4095	0-10vdc/0-20ma
40040	EXP-2 Analog Output-8	2	0-4095	0-10vdc/0-20ma
40041	EXP-2 Freq Input – 1	2	0-5000	0-5000Hz
40042	EXP-2 Freq Input – 2	2	0-5000	0-5000Hz
40043	EXP-2 Reserved	-	-	-
40044	EXP-2 Reserved	-	-	-
40045	EXP-2 Address	2	0-1023	-
40046	EXP-2 Reserved	-	-	-
40047	EXP-2 Reserved	-	-	-
40048	EXP-2 Reserved	-	-	-
40049	EXP-3 Analog Output-1	2	0-4095	0-10vdc/0-20ma
40050	EXP-3 Analog Output-2	2	0-4095	0-10vdc/0-20ma
40051	EXP-3 Analog Output-3	2	0-4095	0-10vdc/0-20ma
40052	EXP-3 Analog Output-4	2	0-4095	0-10vdc/0-20ma
40053	EXP-3 Analog Output-5	2	0-4095	0-10vdc/0-20ma
40054	EXP-3 Analog Output-6	2	0-4095	0-10vdc/0-20ma
40055	EXP-3 Analog Output-7	2	0-4095	0-10vdc/0-20ma
40056	EXP-3 Analog Output-8	2	0-4095	0-10vdc/0-20ma
40057	EXP-3 Freq Input – 1	2	0-5000	0-5000Hz
40058	EXP-3 Freq Input – 2	2	0-5000	0-5000Hz
40059	EXP-3 Reserved	-	-	-
40060	EXP-3 Reserved	-	-	-
40061	EXP-3 Address	2	0-1023	-
40062	EXP-3 Reserved	-	-	-
40063	EXP-3 Reserved	-	-	-
40064	EXP-3 Reserved	-	-	-
40065	EXP-4 Analog Output-1	2	0-4095	0-10vdc/0-20ma
40066	EXP-4 Analog Output-2	2	0-4095	0-10vdc/0-20ma
40067	EXP-4 Analog Output-3	2	0-4095	0-10vdc/0-20ma
40068	EXP-4 Analog Output-4	2	0-4095	0-10vdc/0-20ma
40069	EXP-4 Analog Output-5	2	0-4095	0-10vdc/0-20ma
40070	EXP-4 Analog Output-6	2	0-4095	0-10vdc/0-20ma
40071	EXP-4 Analog Output-7	2	0-4095	0-10vdc/0-20ma
40072	EXP-4 Analog Output-8	2	0-4095	0-10vdc/0-20ma
40073	EXP-4 Freq Input – 1	2	0-5000	0-5000Hz
40074	EXP-4 Freq Input – 2	2	0-5000	0-5000Hz
40075	EXP-4 Reserved	-	-	-
40076	EXP-4 Reserved	-	-	-
40077	EXP-4 Address	2	0-1023	-
40078	EXP-4 Reserved	-	-	-
40079	EXP-4 Reserved	-	-	-
40080	EXP-4 Reserved	-	-	-
40081	EXP-5 Analog Output-1	2	0-4095	0-10vdc/0-20ma
40082	EXP-5 Analog Output-2	2	0-4095	0-10vdc/0-20ma
40083	EXP-5 Analog Output-3	2	0-4095	0-10vdc/0-20ma
40084	EXP-5 Analog Output-4	2	0-4095	0-10vdc/0-20ma
40085	EXP-5 Analog Output-5	2	0-4095	0-10vdc/0-20ma
40086	EXP-5 Analog Output-6	2	0-4095	0-10vdc/0-20ma
40087	EXP-5 Analog Output-7	2	0-4095	0-10vdc/0-20ma
40088	EXP-5 Analog Output-8	2	0-4095	0-10vdc/0-20ma
40089	EXP-5 Freq Input – 1	2	0-5000	0-5000Hz
40090	EXP-5 Freq Input – 2	2	0-5000	0-5000Hz
40091	EXP-5 Reserved	-	-	-
40092	EXP-5 Reserved	-	-	-
40093	EXP-5 Address	2	0-1023	-
40094	EXP-5 Reserved	-	-	-
40095	EXP-5 Reserved	-	-	-
40096	EXP-5 Reserved	-	-	-
40097	EXP-6 Analog Output-1	2	0-4095	0-10vdc/0-20ma
40098	EXP-6 Analog Output-2	2	0-4095	0-10vdc/0-20ma
40099	EXP-6 Analog Output-3	2	0-4095	0-10vdc/0-20ma
40100	EXP-6 Analog Output-4	2	0-4095	0-10vdc/0-20ma
40101	EXP-6 Analog Output-5	2	0-4095	0-10vdc/0-20ma

Modbus Address	Description	#Bytes	D/A Count	(V)/(I)Range
40102	EXP-6 Analog Output-6	2	0-4095	0-10vdc/0-20ma
40103	EXP-6 Analog Output-7	2	0-4095	0-10vdc/0-20ma
40104	EXP-6 Analog Output-8	2	0-4095	0-10vdc/0-20ma
40105	EXP-6 Freq Input – 1	2	0-5000	0-5000Hz
40106	EXP-6 Freq Input – 2	2	0-5000	0-5000Hz
40107	EXP-6 Reserved	-	-	-
40108	EXP-6 Reserved	-	-	-
40109	EXP-6 Address	2	0-1023	-
40110	EXP-6 Reserved	-	-	-
40111	EXP-6 Reserved	-	-	-
40112	EXP-6 Reserved	-	-	-

## Appendix E: Zlinx Wireless I/O Models and Features

Base Modules			
Model Number	Module Type	Frequency/Range	I/O
ZZ24D-NA-SR	Base	2.4 GHz, short range	2AI, 2AO, 2DI, 2DO (sourcing DO's)
ZZ24D-NB-SR	Base	2.4 GHz, short range	4DI, 4DO (sourcing DO's)
ZZ24D-NC-SR	Base	2.4 GHz, short range	2AI, 2AO, 2DI, 2DO (sinking DO's)
ZZ24D-ND-SR	Base	2.4 GHz, short range	4DI, 4DO (sinking DO's)
ZZ24D-NA-MR	Base/Repeater	2.4 GHz, medium range	2AI, 2AO, 2DI, 2DO (sourcing DO's)
ZZ24D-NB-MR	Base/Repeater	2.4 GHz, medium range	4DI, 4DO (sourcing DO's)
ZZ24D-NC-MR	Base/Repeater	2.4 GHz, medium range	2AI, 2AO, 2DI, 2DO (sinking DO's)
ZZ24D-ND-MR	Base/Repeater	2.4 GHz, medium range	4DI, 4DO (sinking DO's)
ZZ9D-NA-MR	Base/Repeater	900 MHz, medium range	2AI, 2AO, 2DI, 2DO (sourcing DO's)
ZZ9D-NB-MR	Base/Repeater	900 MHz, medium range	4DI, 4DO (sourcing DO's)
ZZ9D-NC-MR	Base/Repeater	900 MHz, medium range	2AI, 2AO, 2DI, 2DO (sinking DO's)
ZZ9D-ND-MR	Base/Repeater	900 MHz, medium range	4DI, 4DO (sinking DO's)
ZZ9D-NA-LR	Base/Repeater	900 MHz, long range	2AI, 2AO, 2DI, 2DO (sourcing DO's)
ZZ9D-NB-LR	Base/Repeater	900 MHz, long range	4DI, 4DO (sourcing DO's)
ZZ9D-NC-LR	Base/Repeater	900 MHz, long range	2AI, 2AO, 2DI, 2DO (sinking DO's)
ZZ9D-ND-LR	Base/Repeater	900 MHz, long range	4DI, 4DO (sinking DO's)



ZZ9D-NA-LR-AU (Australian)	Base/Repeater	900 MHz, long range	2AI, 2AO, 2DI, 2DO (sourcing DO's)
ZZ9D-NB-LR-AU (Australian)	Base/Repeater	900 MHz, long range	4DI, 4DO (sourcing DO's)
ZZ9D-NC-LR-AU (Australian)	Base/Repeater	900 MHz, long range	2AI, 2AO, 2DI, 2DO (sinking DO's)
ZZ9D-ND-LR-AU (Australian)	Base/Repeater	900 MHz, long range	4DI, 4DO (sinking DO's)
ZZ8D-NA-LR	Base	868 MHz, long range	2AI, 2AO, 2DI, 2DO (sourcing DO's)
ZZ8D-NB-LR	Base	868 MHz, long range	4DI, 4DO (sourcing DO's)
ZZ8D-NC-LR	Base	868 MHz, long range	2AI, 2AO, 2DI, 2DO (sinking DO's)
ZZ8D-ND-LR	Base	868 MHz, long range	4DI, 4DO (sinking DO's)
<b>Expansion Modules</b>			
<b>Model Number</b>	<b>Type</b>	<b>I/O</b>	<b>I/O Types</b>
ZZ-4AI	Analog Input Module	4AI	mA, V
ZZ-4AO	Analog Output Module	4AO	V, mA(sinking)
ZZ-2AI2AO	Analog Input/Output Module	2AI, 2AO	mA, V
ZZ-8DI-DC	Digital Input Module	8DI	Pull-up, R
ZZ-8DO-T	Digital Output Module	8DO	sourcing
ZZ-8DO-T1	Digital Output Module	8DO	sinking
ZZ-4DI4DO-DCT	Digital Input/Output Module	4DI, 4DO	sourcing
ZZ-4DI4DO- DCT1	Digital Input/Output Module	4DI, 4DO	sinking
ZZ-8DO-R	Digital Output Module	8DO	relays
ZZ-4RTD1	Analog Input Module	4AI	RTD
ZZ-4AO-2	Analog Output Module	4 AO	V, mA(sourcing)

Compatible Radio Modems		
Radio Modem Model	Description	Zlinx Wireless I/O Base Module Model
ZP24D-250RM-SR	2.4 GHz RS-232/422/485 radio modem 250kbps	ZZ24D-NA-SR ZZ24D-NB-SR ZZ24D-NC-SR ZZ24D-ND-SR
ZP24D-96RM-MR	2.4 GHz RS-232/422/485 radio modem 9600 bps	ZZ24D-NA-MR ZZ24D-NB-MR ZZ24D-NC-MR ZZ24D-ND-MR
ZP9D-96RM-MR	900 MHz RS-232/422/485 radio modem 9600 bps	ZZ9D-NA-MR ZZ9D-NB-MR ZZ9D-NC-MR ZZ9D-ND-MR
ZP9D-115RM-LR	900 MHz RS-232/422/485 radio modem 115.2 kbps	ZZ9D-NA-LR ZZ9D-NB-LR ZZ9D-NC-LR ZZ9D-ND-LR ZZ9D-NA-LR-AU ZZ9D-NB-LR-AU ZZ9D-NC-LR-AU ZZ9D-ND-LR-AU
ZP8D-24RM-LR	869.525MHz RS-232/422/485 radio modem 24kbps Throughput 10% Duty Cycle	ZZ8D-NA-LR ZZ8D-NB-LR ZZ8D-NC-LR ZZ8D-ND-LR
Accessories		
Model Number	Description	
ZZ-PROG1	Configuration Box	
ZZ-PROGKIT	Configuration Box and CD with Zlinx Manager software, has serial interface	
ZZ-PROG1-USB	Configuration Box and CD with Zlinx Manager software, has USB interface	
ZZ9D-ANT1	900/868 MHz band antenna	
ZZ24D-ANT1	2.4 GHz band antenna	
ZZ-TB1	Removable terminal block replacement kit	
ZZ-DIN1	DIN rail mounting kit	

## Appendix F: RTD Module

RTD Module ZZ-4RTD1	
<b>Number of RTD:</b>	4
<b>Modbus mode:</b>	Resolution – 16 bits
<b>Peer-to-Peer mode:</b>	Resolution – 12 bits
<b>Wire Configuration:</b>	2, 3, and 4 wire
<b>Type:</b>	Pt100, optimized for temperature coefficient of 385 Pt1000, optimized for temperature coefficient of 385 Cu10, optimized for temperature coefficient of 427
<b>Input connection:</b>	3.5 mm removable terminal block (4 per output)
<b>RTD Module Temperature range:</b>	Pt100 = -200 to 650°C Pt1000 = -200 to 100°C Cu 10 = -100 to 260°C
<b>Resolution:</b>	16 Bit resolution for Modbus mode 12 Bit resolution for Peer-to-Peer mode

### RTD Calculations

#### Converting 0 to 65535 discrete voltage levels to degrees °C in Modbus mode:

1. A Pt100 RTD has a temperature range of -200°C to +650°C which equals a range of 850 degrees.
2. A resolution of 65535 / 850 degrees equals 77.1 steps per 1 degree °C.
3. To convert a reading of 15420 to degrees (°C) perform the following calculation:
  - ❑  $15420 \text{ (reading)} / 77.1 \text{ (steps)} = 200 \text{ (degrees)}$
  - ❑ 200 degree reading with a -200 to 650 range equals 0°C

Another way to look at it:

$D = \# \text{ of degrees across the entire RTD module range}$

- ❑  $-200 \text{ to } 650 = 850 \text{ for PT100}$
- ❑  $D = 850$

$N = \# \text{ of steps per degree} - 65535/D = N$

- ❑  $65535/850 = 77.1$
- ❑  $N = 77.1$

$\text{Current reading}/N = D$

$$15420/77.1 = 200 \text{ degrees}$$

200 degrees is applied across the complete RTD module range. To calculate the true temperature start at the lowest reading and scale up 200 degrees.

$$-200 + 200 \text{ degrees} = 0^\circ\text{C}$$

**Converting a temperature input to a voltage output in Peer-to-Peer Mode:**

1. A Pt100 RTD has a temperature range of -200°C to +650°C which equals a range of 850 degrees.
2. The voltage range is  $(10/4096) * 4095 = FS = 9.998V$
3. Resolution of  $FS / 850$  degrees equals 11.76 mV per 1 degree °C.
4. To convert a temperature to a voltage output, perform the following calculation:
  - ❑ Must offset the temperature by the lower limit, -200 °C, so Temperature – (-200)
  - ❑ Therefore,  $(\text{Temperature} - (-200)) * 0.01176 = \text{Voltage output}$
  - ❑ For a Temperature of 85 °C, Voltage = 3.352 V

**Converting a temperature input to a current output in Peer-to-Peer Mode:**

To convert a temperature to a current output, perform the same calculation shown above but use 20 mA instead of 10 V.

## Appendix G: ZZ-4AO-2 Module

Zlinx Wireless I/O Expansion Module ZZ-4AO-2	
<b>Analog Outputs</b>	4 Sourcing
<b>Resolution:</b>	12 bit, voltage mode and current mode
<b>Accuracy @ 25°C</b>	0-10V Outputs: 0.2% of full scale reading, 0.5% max. 0-20mA Outputs: 0.27% of full scale reading, 0.63% max.
<b>Output source resistance</b>	600 ohm @12V, 1200 ohms @24V; Voltage mode
<b>Output current</b>	1mA; Voltage Mode
<b>Default Mode</b>	Voltage (0-10VDC)
<b>Load, Current Mode</b>	0 to 480 Ohms, 14-30VDC
<b>Load, Voltage Mode</b>	100 Mega ohm
<b>Operation Temp</b>	-40 to 80°C (-40 to 176°F)
<b>Storage Temp</b>	-40 to 85°C (-40 to 185°F)
<b>Operation Humidity</b>	0 to 90% Non-condensing
<b>Power/Source</b>	10-30 VDC / Local Bus
<b>Power Consumption</b>	1.1W (all outputs at 20 mA)

### Analog Output Wiring




Figure 53 Analog Output Wiring scheme

For analog wiring:

1. Connect field wiring to ZZ-4AO-2 Expansion Module as shown above.
2. The analog outputs on this module are sourcing and provide power to the external device.

### Configure Analog Outputs

1. On the Input / Output tab, check to see that all modules and I/O points are listed.
2. Select the ZZ-4AO-2 Module.
3. Set the Analog Outputs for 1 to 10VDC or, 0 to 20mA as needed (setting one sets all for module).

The ZZ-4AO-2 model is a sourcing output and does not require a power supply to complete the loop. Since the current is sourced there is no need to use an isolator or differential input. This output can connect directly to a standard 0-20mA input.

## Operation Test

LED Indications During Normal Operation:

LED	Status	Function
Power (Red)	Solid	Power Applied
Data (Green)**	Off Blinking	No Data Link Data Traffic
Bus (Green)	Off Blinking	No Local Bus Local Bus Traffic

\*\*Data LED located on Base Module only.

### System Test Procedure using Modscan32 Program

Configure as follows:

- Baud Rate Setting: 9600, N, 8, 1.
- Modbus Mode.
- Slave Address 1.

Launch and configure Modscan32:

- Main Menu:
  - Address = 1.
  - Length = 16.
  - Modbus Point Type = 02: Input Status.
  - Device ID = 1.
- Communications Set Up (Connection Tab):
  - Select a COM Port from Connect Using the pull down.
  - Select 9600 from Configuration Baud pull down.
  - Select 8 from Configuration Word Length pull down.
  - Select None from Configuration Parity pull down.
  - Select 1 from Configuration Stop Bits pull down.
- Protocol Selection:
  - Select RTU under Transmission Mode.
  - Select nothing under "DANIEL/ENRON/OMNI".
  - Enter 1500 in Slave Response Time Out Block.
  - Enter 5 in Delay Between Polls.
  - Click OK to Exit.
  - Click OK again to Exit Main Connection Details.

The program should now operate. There are two counters that count the “number of polls” and “valid Slave responses.” They don’t need to be the same, but they should both increment and be close to each other. Inputs can be toggled and the status should change in the Modbus table.

## Appendix I: Convert Voltage to DAC

### 1. Going from Voltage to Modbus Holding Register value:

Voltage Full Range = 10VDC

DAC full range is 4096 counts, 4096

Voltage Desired \* 4096/10 = Holding Register Value to Send

### 2. Going from Current to Modbus Holding Register value:

Current Full Range = 20mA

DAC full range is 4096 counts, 4096

Current Desired \* 4096/20 = Holding Register Value to Send

### 3. Going from Modbus Input Register to Voltage value:

Voltage Full Range = 10VDC

DAC full range is 4096 counts, 4096

Input Register \* 10/4096 = Voltage Value

### 4. Going from Modbus Input Register to Current value:

Current Full Range = 20mA

DAC full range is 4096 counts, 4096

Input Register \* 20/4096 = Voltage Value



## Product Updates

This section summarizes changes made in current product version.

### Generation II:

#### Firmware Version

ZLINX-IO Base V3.xx.hex,

#### ZLINX IO Manager V3.1.0.8

- Enables AES Encryption
- Enables OTA Data Rate Selection
- Enables RF Transmit Power Selection

#### Firmware version

ZLINX-IO Base V3.12.hex, ZLINX-IO Exp V3.10.hex.

#### Software version

ZLINX IO Manager V3.0.0 RC19

- Failsafe functions
- DO-1 Communication Failure Dedicated Alarm Output).
- User calibration
- Exception Based Reporting ).
- System Data Monitor ).
- Overall data Latency improvement

### Generation I:

- Choice of number and type of digital and analog I/O.
- Sourcing or sinking digital outputs available.
- Flexible and scalable by adding expansion modules.
- Wireless MODBUS and Peer-to-Peer communications modes.
- Small, economical and configurable.
- Wide operating temperature range.
- AC or DC power sources.
- Three radio options for different range capabilities.
- Power, RSSI, RF Data and Bus LED's.
- Removable screw terminal strips for power supply and I/O points.

- Zlinx Manager Configuration software.
- DIN rail mountable.

# Glossary

## ADC

Analog to digital converter.

## Analog Input (AI)

An analog input is a measurable electrical signal with a defined range that is generated by a sensor and received by a controller. The analog input changes continuously in a definable manner in relation to the measured property.

## Analog Output (AO)

An analog output is a measurable electrical signal with a defined range that is generated by a controller and sent to a controlled device, such as a variable speed drive or actuator. Changes in the analog output cause changes in the controlled device that result in changes in the controlled process.

## Cu10

Copper 10 Resistance thermometers, also called resistance temperature detectors (RTDs), are temperature sensors that exploit the predictable change in electrical resistance of some materials with changing temperature. They are slowly replacing the use of thermocouples in many industrial applications below 600 °C, due to higher accuracy and repeatability.

## DCE

Data Communications Equipment. This indicates how a serial cable, DB9 or DB25 is pinned out as far as inputs and outputs are concerned. A straight through serial cable can be used when connecting a DTE device to a DCE device, but a null modem cable is required to connect a DCE to DCE or DTE to DTE device.

## DIN

A standardized 35 mm wide metal rail used for mounting industrial equipment inside racks and enclosures.

## Digital Input (DI)

A digital input typically consists of a power supply (voltage source), a switch and a voltage-sensing device (analog-to-digital converter). Depending on the switch's open/closed status, the sensing device detects a voltage or no voltage condition, which in turn generates a logical 0 or 1, ON or OFF, alarm or normal or similarly defined state.

## Digital Output (DO)

A digital output typically consists of a switch (either mechanical as in a relay, or electronic as in a transistor or triac) that either opens or closes the circuit between two terminals depending on the binary state of the output.

## FCC

The Federal Communications Commission (FCC) is an independent United States government agency. The FCC was established by the Communications Act of 1934 and is charged with regulating interstate and international communications by radio, television, wire, satellite and cable. The FCC's jurisdiction covers the 50 states, the District of Columbia, and U.S. possessions.

## LOS

Line-of-sight propagation refers to electro-magnetic radiation including light emissions traveling in a straight line. The rays or waves are diffracted, refracted, reflected, or absorbed by atmosphere and obstructions with material and generally cannot travel over the horizon or behind obstacles.

## PLC

Programmable controllers operate by producing signals that are sent to devices connected to PLC outputs.

### **Pt100**

Platinum 100 Resistance thermometers, also called resistance temperature detectors (RTDs), are temperature sensors that exploit the predictable change in electrical resistance of some materials with changing temperature. As they are almost invariably made of platinum, they are often called platinum resistance thermometers (PRTs). They are slowly replacing the use of thermocouples in many industrial applications below 600 °C, due to higher accuracy and repeatability.

### **Pt1000**

Platinum 1000 Resistance thermometers, also called resistance temperature detectors (RTDs), are temperature sensors that exploit the predictable change in electrical resistance of some materials with changing temperature. As they are almost invariably made of platinum, they are often called platinum resistance thermometers (PRTs). They are slowly replacing the use of thermocouples in many industrial applications below 600 °C, due to higher accuracy and repeatability. Suitable for air, water, oil and fuel temperature measurement.

### **RTD**

Resistance thermometers, also called resistance temperature detectors (RTDs), are temperature sensors that exploit the predictable change in electrical resistance of some materials with changing temperature. As they are almost invariably made of platinum, they are often called platinum resistance thermometers (PRTs). They are slowly replacing the use of thermocouples in many industrial applications below 600 °C, due to higher accuracy and repeatability.

### **RSSI**

In wireless communications, received signal strength indication (RSSI) is a measurement of the power present in a received radio signal.

### **Sinking**

Refers to a device or component that accepts (absorbs) current. Conventional current flows into this sinking device.

### **Sourcing**

Refers to a device or component that provides current. Conventional current flows out of a sourcing device.

### **SCADA**

Supervisory Control And Data Acquisition. It generally refers to an industrial control system: a computer system monitoring and controlling a process. The process can be industrial, infrastructure or facility based as described below.

---

**Index**

---

**A**

AC, 24  
AO, 14

**B**

Base Module, 14

**C**

Configuration Box, 15  
Cu 10, 46

**D**

DC, 24  
DCE, 25  
DI, 14  
DIN, 27  
DO, 14

**E**

Expansion Module, 14

**L**

LED, 24  
LOS, 28  
LR, 14

**M**

Modbus map, 21  
Modbus Mode, 5  
Modes of Operation, 4  
MR, 14

**P**

Peer-to-Peer Mode, 4  
PLC, 16  
Pt100, 46  
Pt1000, 46

**R**

Repeater Mode, 6  
RTD, 16

**S**

SCADA, 16  
sinking, 28  
sourcing, 28  
SR, 14

**Z**

Zlinx Manager, 29